



P4i45PE

# User Manual

Version 3.0

Published October 2003

Copyright©2003 ASRock INC. All rights reserved.

---

## Copyright Notice:

No part of this manual may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Inc.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

## Disclaimer:

Specifications and information contained in this manual are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock. ASRock assumes no responsibility for any errors or omissions that may appear in this manual.

With respect to the contents of this manual, ASRock does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock has been advised of the possibility of such damages arising from any defect or error in the manual or product.

**ASRock Website: <http://www.asrock.com>**

---

# Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
1.1	Package Contents	4
1.2	Specifications	5
1.3	Motherboard Layout	8
1.4	ASRock I/O™	9
<b>2</b>	<b>Installation</b>	<b>10</b>
2.1	Screw Holes	10
2.2	Pre-installation Precautions	10
2.3	CPU Installation	11
2.4	Installation of CPU fan and Heatsink	11
2.5	Installation of Memory Modules (DIMM)	12
2.6	Expansion Slots (PCI and AGP Slots)	13
2.7	Jumpers Setup	14
2.8	Connectors	15
<b>3</b>	<b>BIOS Setup</b>	<b>17</b>
3.1	BIOS Setup Utility	17
3.1.1	BIOS Menu Bar	17
3.1.2	Legend Bar	17
3.2	Main Menu	18
3.3	Advanced, Security, Power, Boot, and Exit Menus	20
<b>4</b>	<b>Software Support</b>	<b>21</b>
4.1	Installing Operating System	21
4.2	Support CD Information	21
4.2.1	Running Support CD	21
4.2.2	Drivers Menu	21
4.2.3	Utilities Menu	21
4.2.4	ASRock "PC-DIY Live Demo" Program	21
4.2.5	Contact Information	21
	<b>Appendix</b>	<b>22</b>
1.	Advanced BIOS Setup Menu	22
2.	Security Setup Menu	27
3.	Power Setup Menu	28
4.	Boot Setup Menu	29
5.	Exit Menu	30

---

# Chapter 1 Introduction

Thank you for purchasing ASRock P4i45PE motherboard, a reliable motherboard produced under ASRock's consistently stringent quality control. It delivers excellent performance with robust design conforming to ASRock's commitment to quality and endurance.

Chapter 1 and 2 of this manual contain introduction of the motherboard and step-by-step installation guide for new DIY system builders. Chapter 3 and 4 contain basic BIOS setup and Support CD information.

For advanced users' reference, the Appendix appearing on page 22 offers more advanced BIOS setup information.



Because the motherboard specifications and the BIOS software might be updated, the content of this manual will be subject to change without notice. In case any modifications of this manual occur, the updated version will be available on ASRock website without further notice. You may find the latest memory and CPU support lists on ASRock website as well.

ASRock website <http://www.asrock.com>

## 1.1 Package Contents

ASRock P4i45PE Motherboard (ATX Form Factor: 12.0-in x 7.0-in, 30.5 cm x 17.8 cm)

ASRock P4i45PE Quick Installation Guide

ASRock P4i45PE Support CD

One 80-conductor Ultra ATA 66/100 IDE Ribbon Cable

One Ribbon Cable for a 3.5-in Floppy Drive

One ASRock I/O™ Shield

---

## 1.2 Specifications

<b>Platform:</b>	ATX Form Factor (12.0-in x 7.0-in, 30.5 cm x 17.8 cm)
<b>CPU:</b>	Socket 478 for Intel® Pentium® 4/ Celeron® processor
<b>Chipsets:</b>	North Bridge: Intel® 845PE chipsets, standard FSB @ 533 / 400MHz, Max. 800+ MHz at overclocking mode (see <b>CAUTION 1</b> ), supports Hyper-Threading Technology (see <b>CAUTION 2</b> ); South Bridge: Intel® ICH4
<b>Memory:</b>	2 DDR DIMM slots: DDR1 and DDR2 PC2100 (DDR266) / PC2700 (DDR333), Max. 2GB PC3200 (DDR400) at overclocking mode, Max. 1GB
<b>IDE:</b>	IDE1: ATA 100 / Ultra DMA Mode 5; IDE2: ATA 100 / Ultra DMA Mode 5; Supports up to 4 IDE devices
<b>Floppy Port:</b>	Supports up to 2 floppy disk drives
<b>Audio:</b>	5.1 channels AC'97 Audio
<b>PCI LAN:</b>	Speed: 802.3u (10/100 Ethernet), supports Wake-On-LAN
<b>Hardware Monitor:</b>	CPU temperature sensing (ASRock U-COP); Chassis temperature sensing; CPU overheat shutdown to protect CPU life (ASRock U-COP)(see <b>CAUTION 3</b> ); CPU fan tachometer; Chassis fan tachometer; Voltage monitoring: +12V, +5V, +3V, Vcore
<b>PCI slots:</b>	5 PCI slots with PCI Specification 2.2
<b>AGP slot:</b>	1 AGP slot, supports 1.5V, 4X AGP card (see <b>CAUTION 4</b> )
<b>USB 2.0:</b>	4 default USB 2.0 ports and one extra set of header for two additional USB 2.0 ports upgrade (see <b>CAUTION 5</b> )
<b>ASRock I/O™:</b>	PS/2: 1 keyboard port / 1 mouse port; 1 RJ 45 port; 4 rear default USB 2.0 ports; 1 serial port: COM1; 1 parallel port: ECP/EPP support; Audio Jack: Line Out / Line In / Microphone + 1 Game port
<b>BIOS:</b>	AMI legal BIOS; Supports "Plug and Play"; ACPI 1.1 compliance wake up events; Supports jumperfree; SMBIOS 2.3.1 support; CPU frequency stepless control (only for advanced users' reference, see <b>CAUTION 6</b> );
<b>OS:</b>	Microsoft® Windows® 98 SE / ME / 2000 / XP compliant

---

## **CAUTION!**

1. P4i45PE motherboard may be fine tuned to support higher CPU bus frequencies on certain condition (over-clocking mode). Please refer to the NOTE on page 7 for the details.
2. About the setting of “Hyper Threading Technology”, please check page 22.
3. While CPU overheat is detected, the system will automatically shutdown. Please check if the CPU fan on the motherboard functions properly before you resume the system. To improve heat dissipation, remember to spray thermal grease between the CPU and the heatsink when you install the PC system.
4. Do NOT plug a 3.3V AGP card in the AGP slot on P4i45PE motherboard! It may cause permanent damage!
5. Power Management for USB 2.0 works fine under Microsoft® Windows® XP SP1 / 2000 SP4. It may not work properly under Microsoft® Windows® 98 / ME. Please refer to Microsoft® official document at <http://www.microsoft.com/whdc/hwdev/bus/USB/USB2support.mspx>
6. Although P4i45PE offers stepless control, it is not recommended to perform over clocking. When the CPU frequency of P4i45PE is set to perform over clocking, other clocks, such as PCI clock, AGP clock, and Memory clock will also be overclocked proportionally. Frequencies other than the recommended CPU bus frequencies may cause the instability of the system or damage the CPU and the motherboard.

## NOTE

P4i45PE may be fine tuned to support higher CPU front side bus frequencies on certain condition at over-clocking mode. Please refer to the tables below for the details.

	CPU FSB	Configuration Note
P4i45PE	800 MHz	1. Set the "FSB" jumper to "800" mode (see page 14).
		2. Only support one DDR 400 memory module on DDR1 DIMM. (If it is set to DDR 400 mode, then it does not support CL3 module.)
		3. Update BIOS version to 2.10 or later version.


The Recommended Memory Modules lists for **P4i45PE** motherboard.

### FSB 800 MHz / DDR 400 Mode

DRAM VENDOR	SIZE (MB)	TYPE	CELL VENDOR	CELL NO.	SINGLE SIDE / DOUBLE SIDE
ADATA	512	DDR400	ADATA	ADD8608A8A-58	DOUBLE SIDE
ADATA	256	DDR450	ADATA	ADD8608A8A-4.58	SINGLE SIDE
ADATA	256	DDR400	WINBOND	W942508CH-5	SINGLE SIDE
APACER	512	DDR400	PSC	A2S56D30ATP	DOUBLE SIDE
APACER	512	DDR400	SAMSUNG	K4H560838D-TCCC	DOUBLE SIDE
APACER	256	DDR400	INFINEON	HYB25D256800BT-5	SINGLE SIDE
APACER	256	DDR400	SAMSUNG	K4H560838D-TCCC	SINGLE SIDE
INFINEON	256	DDR400	INFINEON	HYB25D256800BT-5	SINGLE SIDE
INFINEON	128	DDR400	INFINEON	HYB250256160BT-5	SINGLE SIDE
KINGMAX	512	DDR400	KINGMAX	KDL3888P4EA-50	DOUBLE SIDE
KINGMAX	256	DDR400	KINGMAX	KDL684T4AA-50	SINGLE SIDE
KINGSTON	256	DDR400	MOSEL	V58C2256804SAT5	SINGLE SIDE
KINGSTON	256	DDR400	HYNIX	HY5DU56822BT-D43	SINGLE SIDE
KINGSTON	256	DDR400	WINBOND	W942508CH-5	SINGLE SIDE
MICRON	128	DDR400	MICRON	46V16M8	SINGLE SIDE
SAMSUNG	512	DDR400	SAMSUNG	K4H560838D-TCCC	DOUBLE SIDE
SAMSUNG	256	DDR400	SAMSUNG	K4H560838E-TCC C	SINGLE SIDE
TWINMOS	512	DDR400	M.tec	TTD7608F8E50B	DOUBLE SIDE
TWINMOS	256	DDR466	TWINMOS	TMD7608F8E43B	SINGLE SIDE
TWINMOS	256	DDR400	TWINMOS	TMD7608F8E50B	SINGLE SIDE
TWINMOS	256	DDR400	M.tec	TTD7608F8E50B	SINGLE SIDE

Since the memory types are changing rapidly, please visit ASRock website (<http://www.asrock.com/support/index.htm>) for the latest recommended memory support list.

## 1.3 Motherboard Layout




- |    |                                       |    |  |
|----|---------------------------------------|----|--|
| 1  | FSB Select Jumper (FSB)               | 15 | Chassis Speaker Connector (SPEAKER 1)  |
| 2  | PS2_USB_PWR1 Jumper                   | 16 | System Panel Connector (PANEL1)        |
| 3  | CPU Heatsink Retention Module         | 17 | Infrared Module Connector (IR1)        |
| 4  | CPU Socket                            | 18 | USB 2.0 Header (USB45, Blue)           |
| 5  | North Bridge Controller               | 19 | BIOS FW Chip                           |
| 6  | 184-pin DDR DIMM Slots (DDR1-2)       | 20 | PCI Slots (PCI1-5)                     |
| 7  | ATX Power Connector (ATXPWR1)         | 21 | PCI LAN                                |
| 8  | Secondary IDE Connector (IDE2, Black) | 22 | JL1 Jumper                             |
| 9  | Primary IDE Connector (IDE1, Blue)    | 23 | JR1 Jumper                             |
| 10 | AGP Slot (1.5V_AGP1)                  | 24 | Front Panel Audio Connector (AUDIO1)   |
| 11 | South Bridge Controller               | 25 | Internal Audio Connector: AUX1 (White) |
| 12 | Chassis Fan Connector (CHA_FAN1)      | 26 | Internal Audio Connector: CD1 (Black)  |
| 13 | Clear CMOS Jumper (CLRCMOS0)          | 27 | CPU Fan Connector (CPU_FAN1)           |
| 14 | Floppy Connector (FLOPPY1)            |    |  |



---

## 1.4 ASRock I/O™



- |   |                      |    |                             |
|---|----------------------|----|-----------------------------|
| 1 | Parallel Port        | 6  | Line Out (Lime)             |
| 2 | RJ-45 Port           | 7  | USB 2.0 Ports               |
| 3 | Game Port            | 8  | Serial Port (COM1)          |
| 4 | Microphone (Pink)    | 9  | PS/2 Keyboard Port (Purple) |
| 5 | Line In (Light Blue) | 10 | PS/2 Mouse Port (Green)     |

---

## Chapter 2 Installation

P4i45PE is an ATX form factor (12.0-in x 7.0-in, 30.5 cm x 17.8 cm) motherboard. Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it.



Make sure to unplug the power cord before installing or removing the motherboard. Failure to do so may cause physical injuries to you and damages to motherboard components.

### 2.1 Screw Holes

Place screws into the holes indicated by circles to secure the motherboard to the chassis.



Do not over-tighten the screws! Doing so may damage the motherboard.

### 2.2 Pre-installation Precautions

Take note of the following precautions before you install motherboard components or change any motherboard settings.

1. Unplug the power cord from the wall socket before touching any component.
2. To avoid damaging the motherboard components due to static electricity, NEVER place your motherboard directly on the carpet or the like. Also remember to use a grounded wrist strap or touch a safety grounded object before you handle components.
3. Hold components by the edges and do not touch the ICs.
4. Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that comes with the component.

**Before you install or remove any component, ensure that the power is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.**

---


## 2.3 CPU Installation

- Step 1. Unlock the socket by lifting the lever up to a 90° angle.
- Step 2. Position the CPU directly above the socket such that its marked corner matches the base of the socket lever.
- Step 3. Carefully insert the CPU into the socket until it fits in place.



The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to avoid bending of the pins.

- Step 4. When the CPU is in place, press it firmly on the socket while you push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked.



Step 1



Step 2, 3



Step 4

## 2.4 Installation of CPU Fan and Heatsink

Intel® Pentium®4 CPU requires larger heatsink and cooling fan. Thermal grease between the CPU and the heatsink is also needed to improve heat dissipation. Make sure that the CPU and the heatsink are securely fastened and in good contact with each other. Then connect the CPU fan to the CPU\_FAN connector (CPU\_FAN1, see page 8, No. 27). For proper installation, please kindly refer to the instruction manuals of the CPU fan and heatsink vendors.

---



## 2.5 Installation of Memory Modules (DIMM)

P4i45PE motherboard provides two 184-pin DDR (Double Data Rate) DIMM slots.



Please make sure to disconnect power supply before adding or removing DIMMs or the system components.

- Step 1. Unlock a DIMM slot by pressing the retaining clips outward.
- Step 2. Align a DIMM on the slot such that the notch on the DIMM matches the break on the slot.



The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.

- Step 3. Firmly insert the DIMM into the slot until the retaining clips at both ends fully snap back in place and the DIMM is properly seated.

---

## 2.6 Expansion Slots (PCI and AGP Slots)

There are 5 PCI slots and 1 AGP slot on P4i45PE motherboard.

**PCI slots:** PCI slots are used to install expansion cards that have the 32-bit PCI interface.

**AGP slot:** The AGP slot is used to install a graphics card. The ASRock AGP slot has a special locking mechanism which can securely fasten the graphics card inserted.




Please do not plug a 3.3V AGP card in the AGP slot on P4i45PE motherboard! It may cause permanent damage!



### Installing an expansion card



- Step 1. Before installing the expansion card, please make sure that the power supply is switched off or the power cord is unplugged. Please read the documentation of the expansion card and make necessary hardware settings for the card before you start the installation.
- Step 2. Remove the system unit cover (if your motherboard is already installed in a chassis).
- Step 3. Remove the bracket facing the slot that you intend to use. Keep the screws for later use.
- Step 4. Align the card connector with the slot and press firmly until the card is completely seated on the slot.
- Step 5. Fasten the card to the chassis with screws.
- Step 6. Replace the system cover.

## 2.7 Jumpers Setup

The illustration shows how jumpers are setup. When the jumper cap is placed on pins, the jumper is “Short”. If no jumper cap is placed on pins, the jumper is “Open”. The illustration shows a 3-pin jumper whose pin1 and pin2 are “Short” when jumper cap is placed on these 2 pins.



Jumper	Setting	Description
FSB (see p.8 item 1)	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1_2</p>  <p><b>NORMAL</b></p> </div> <div style="text-align: center;"> <p>2_3</p>  <p><b>800</b></p> </div> </div>	<p>“NORMAL” (short pin1, pin2) is the default setting for the FSB jumper. “800” (short pin2, pin3) is the setting for the over clocking of CPU frequency.</p>

PS2_USB_PWR1 (see p.8 item 2)	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1_2</p>  <p><b>+5V</b></p> </div> <div style="text-align: center;"> <p>2_3</p>  <p><b>+5VSB</b></p> </div> </div>	<p>Short pin2, pin3 to enable +5VSB (standby) for PS/2 or USB wake up events.</p>
----------------------------------	--	---

Note: To select +5VSB, it requires 2 Amp and higher standby current provided by power supply.

JR1 (see p.8 item 23)	
JL1 (see p.8 item 22)	

Note: If the jumpers JL1 and JR1 are short, both the front panel and the rear panel audio connectors can work.



Clear CMOS (CLR CMOS0) (see p.8 item 13)	 <b>2-pin jumper</b>
--	--

Note: CLR CMOS0 allows you to clear the data in CMOS. The data in CMOS includes system setup information such as system password, date, time, and system setup parameters. To clear and reset the system parameters to default setup, please turn off the computer and unplug the power cord, then use a jumper cap to short the pins on CLR CMOS0 for 3 seconds. Please remember to remove the jumper cap after clearing the CMOS.

## 2.8 Connectors



Connectors are NOT jumpers. DO NOT place jumper caps over these connectors.

Connector	Figure	Description
FDD connector (33-pin FLOPPY1) (see p.8 item 14)		

Note: Make sure the red-striped side of the cable is plugged into Pin1 side of the connector.


Primary IDE connector (Blue) (39-pin IDE1, see p.8 item 9)      Secondary IDE connector (Black) (39-pin IDE2, see p.8 item 8)



connect the blue end to the motherboard      connect the black end to the IDE devices  
80-conductor ATA 66/100 cable


Note: If you use only one IDE device on this motherboard, please set the IDE device as "Master". Please refer to the instruction of your IDE device vendor for the details. Besides, to optimize compatibility and performance, please connect your hard disk drive to the primary IDE connector (IDE1, blue) and CD-ROM to the secondary IDE connector (IDE2, black).

USB 2.0 Header  
(9-pin USB45)  
(see p.8 item 18)



ASRock I/O™ provides you 4 default USB 2.0 ports on the rear panel. If the rear USB ports are not sufficient, this header is available to support 2 additional USB 2.0 ports.

Infrared module connector  
(5-pin IR1)  
(see p.8 item 17)



This connector supports an optional wireless transmitting and receiving infrared module.


---

### Internal audio connectors

(4-pin CD1, 4-pin AUX1)

(CD1: see p.8 item 26)

(AUX1: see p.8 item 25)




These connectors allow you to receive stereo audio input from sound sources such as a CD-ROM, DVD-ROM, TV tuner card, or MPEG card.

---

### Front panel audio connector

(9-pin AUDIO1)

(see p.8 item 24)




This is an interface for front panel audio cable that allows convenient connection and control of audio devices.

---

### System panel connector

(9-pin PANEL1)

(see p.8 item 16)




This connector accommodates several system front panel functions.

---

### Chassis speaker connector

(4-pin SPEAKER 1)

(see p.8 item 15)




This connector allows you to attach to an external speaker.

---

### Chassis fan connector

(3-pin CHA\_FAN1)

(see p.8 item 12)




Connect the fan cable to the connector matching the black wire to the ground pin.

---

### CPU fan connector

(3-pin CPU\_FAN1)

(see p.8 item 27)



Connect the fan cable to the connector matching the black wire to the ground pin.

---

### ATX power connector

(20-pin ATXPWR1)

(see p.8 item 7)



Connect an ATX power supply to the connector.



---

# Chapter 3 BIOS Setup

## 3.1 BIOS Setup Utility

This section explains how to configure your system using the BIOS Setup Utility. The BIOS FWH chip on the motherboard stores the BIOS Setup Utility. When you start up the computer, there is a chance for you to run the BIOS Setup. Press <F2> during the Power-On-Self-Test (POST) to enter the BIOS Setup Utility, otherwise, POST continues with its test routines.

If you wish to enter the BIOS Setup after POST, restart the system by pressing <Ctl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You can also restart by turning the system off and then back on.

The BIOS Setup Utility is designed to be user-friendly. It is a menu-driven program, which allows you to scroll through its various sub-menus and select among the predetermined choices.



Because the BIOS software is constantly being updated, the following BIOS setup screens and descriptions are for reference purpose only, and may not exactly match what you see on your screen.

### 3.1.1 BIOS Menu Bar

The top of the screen has a menu bar with the following selections:

<b>MAIN</b>	Sets up the basic system configuration
<b>ADVANCED</b>	Sets up the advanced features
<b>SECURITY</b>	Sets up the security features
<b>POWER</b>	Configures Power Management features
<b>BOOT</b>	Configures the default system device that is used to locate and load the Operating System
<b>EXIT</b>	Exits the current menu or the BIOS Setup

To access the menu bar items, press the right or left arrow key on the keyboard until the desired item is highlighted.


### 3.1.2 Legend Bar

At the bottom of the Setup Screen is a legend bar. The following table lists the keys in the legend bar with their corresponding functions.

Navigation Key(s)	Function Description
<F1>	Displays the General Help Screen
<ESC>	Jumps to the Exit menu or returns to the upper menu from the current menu
↑ / ↓	Moves cursor up or down between fields
← / →	Selects menu to the left or right
+ / -	Increases or decreases values
<Enter>	Brings up a selected menu for a highlighted field
<F9>	Loads all the setup items to the default values
<F10>	Saves changes and exits Setup

### 3.2 Main Menu

When you enter the BIOS Setup Utility, the following screen appears.



#### System Date [Month/Day/Year]

Set the system date that you specify. Valid values for month, day, and year are Month: (Jan to Dec), Day: (1 to 31), Year: (up to 2099). Use ↑ ↓ keys to move between the Month, Day and Year fields.

#### System Time [Hour:Minute:Second]

Set the system to the time that you specify. Use ↑ ↓ keys to move between the Hour, Minute and Second fields.

#### Floppy Drives

Use this to set the type of floppy drives installed.

#### IDE Devices

Use this to configure IDE devices.

## TYPE

To set the type of the IDE device, first, please select “IDE Devices” on Main menu and press <Enter> to get into the sub-menu. Then, select among “Primary IDE Master”, “Primary IDE Slave”, “Secondary IDE Master”, and “Secondary IDE Slave” to make configuration of its type. After making your selections on this sub-menu, press <ESC> key to return to the upper menu, in which the hard disk drive field will display the size of the hard disk drive that you configured. Below are the configuration options.

AMIBIOS SETUP UTILITY - VERSION 3.31a	
Main	
Primary IDE Master:	
Type	Auto
Cylinders	
Heads	
Write Precompensation	
Sectors	
Maximum Capacity	
LBA Mode	On
Block Mode	On
Fast Programmed I/O Modes	Auto
32 Bit Transfer Mode	On
Ultra DMA Mode	Auto
[ Setup Help ]	
Select how to set the parameters of drive, Or Select [AUTO] to set all HDD parameters automatically.	
F1:Help Esc:Previous Menu	F9:Setup Defaults F10:Save & Exit
↑:Select Item +/-:Change Values Enter>Select	▶Sub-Menu

**[USER]:** It allows user to manually enter the number of cylinders, heads, and sectors per track for the drive.



Before attempting to configure a hard disk drive, make sure you have the correct configuration information supplied by the drive manufacturer. Incorrect settings may cause the system to fail to recognize the installed hard disk.

**[Auto]:** Select [Auto] to automatically detect hard disk drive. If auto-detection is successful, the BIOS Setup automatically fills in the correct values for the remaining fields on this sub-menu. If the auto-detection fails, it may be due to that the hard disk is too old or too new. If the hard disk was already formatted on an older system, the BIOS Setup may detect incorrect parameters. In these cases, select [User] to manually enter the IDE hard disk drive parameters.



After entering the hard disk information into BIOS, use a disk utility, such as FDISK, to partition and format new IDE hard disk drives. This is necessary so that you can write or read data from the hard disk. Make sure to set the partition of the Primary IDE hard disk drives to active.

---

**[CD/DVD]:** This is used for IDE CD/DVD drives.

**[ARMD]:** This is used for IDE ARMD (ATAPI Removable Media Device), such as MO.

### **Cylinders**

This is used to configure the number of cylinders. Refer to the drive documentation to determine the correct value.

### **Heads**

This is used to configure the number of read/write heads. Refer to the drive documentation to determine the correct values.

### **Write Pre-compensation**

Enter Write Pre-compensation sector. Refer to the drive documentation to determine the correct value.

### **Sectors**

This is used to configure the number of sectors per track. Refer to the drive documentation to determine the correct value.

### **Maximum Capacity**

This field shows the drive's maximum capacity as calculated by the BIOS based on the drive information you entered.

### **LBA Mode**

This allows user to select the LBA mode for a hard disk > 512 MB under DOS and Windows; for Netware and UNIX user, select [Off] to disable the LBA mode.

### **Block Mode**

Set the block mode to [On] will enhance hard disk performance by reading or writing more data during each transfer.

### **Fast Programmed I/O Modes**

This allows user to set the PIO mode to enhance hard disk performance by optimizing the hard disk timing.

### **32 Bit Transfer Mode**

It allows user to enable 32-bit access to maximize the IDE hard disk data transfer rate.

### **Ultra DMA Mode**

Ultra DMA capability allows improved transfer speeds and data integrity for compatible IDE devices. Set to [Disabled] to suppress Ultra DMA capability.

## **3.3 Advanced, Security, Power, Boot, and Exit Menus**

Detailed descriptions of these menus are listed in the Appendix. See page 22.

---

# Chapter 4 Software Support

## 4.1 Install Operating System

This motherboard supports various Microsoft® Windows® operating systems: 98 SE / ME / 2000 / XP. Because motherboard settings and hardware options vary, use the setup procedures in this chapter for general reference only. Refer to your OS documentation for more information.

## 4.2 Support CD Information

The Support CD that came with the motherboard contains necessary drivers and useful utilities that will enhance the motherboard features.

### 4.2.1 Running The Support CD

To begin using the support CD, insert the CD into your CD-ROM drive. The CD automatically displays the Main Menu if "AUTORUN" is enabled in your computer. If the Main Menu did not appear automatically, locate and double click on the file ASSETUP.EXE from the BIN folder in the Support CD to display the menus.

### 4.2.2 Drivers Menu

The Drivers Menu shows the available devices drivers if the system detects installed devices. Install the necessary drivers to activate the devices.

### 4.2.3 Utilities Menu

The Utilities Menu shows the applications software that the motherboard supports. Click on a specific item then follow the installation wizard to install it.

### 4.2.4 ASRock PC-DIY Live Demo Program

ASRock presents you a multimedia PC-DIY live demo, which shows you how to install your own PC system step by step. You can find the file through the following path:

..\MPEGAV\AVSEQ01.DAT

To see this demo program, you may run Microsoft® Media Player® to play the file.

### 4.2.5 Contact Information

If you need to contact ASRock or want to know more about ASRock, welcome to visit ASRock's website at <http://www.asrock.com>; or you may contact your dealer for further information.

---

## Appendix: Advanced BIOS Setup

This section will introduce you the following BIOS Setup menus: "Advanced," "Security," "Power," "Boot," and "Exit."

### 1. Advanced BIOS Setup Menu

AMIBIOS SETUP UTILITY - VERSION 3.31a			
Main	Advanced	Security	Power Boot Exit
Spread Spectrum		Disabled	[ Setup Help ]
CPU Host Frequency		Auto	<Enter> to enable or disable the feature of spread spectrum.
Actual Frequency		133MHz	
CPU Ratio Selection		Locked	
SDRAM Frequency		Auto	
Hyper Threading Technology		Auto	
▶ Chipset Configuration			
▶ Resource Configuration			
▶ Peripheral Configuration			
▶ System Hardware Monitor			
F1:Help	↑↓:Select Item	+/-:Change Values	F9:Setup Defaults
Esc:Exit	←→:Select Menu	Enter:Select ▶Sub-Menu	F10:Save & Exit

#### Spread Spectrum:

This field should always be [Disabled] for better system stability.

#### CPU Host Frequency:

This shows current CPU host frequency of the installed motherboard.

#### CPU Ratio Selection:

CPU Ratio is the multiple that times the frontside bus frequency will equal the core speed of the installed processor. Whether the option is open or locked is determined by the installed processor.

#### SDRAM Frequency:

If set to [Auto], the motherboard will detect the inserted memory module(s) and automatically assign appropriate frequency. For the setting of FSB 533, you may select [133MHz (DDR 266)], [166MHz (DDR 333)] as the operating frequency. For the setting of FSB 400, you may select [100MHz (DDR 200)], [133MHz (DDR 266)] as the operating frequency.

#### Hyper Threading Technology:

To enable this feature, it requires a computer system with an Intel Pentium®4 processor that supports Hyper-Threading Technology and an operating system that includes optimization for this technology, such as Microsoft® Windows® XP. Set to [Auto] if using Microsoft® Windows® XP, or Linux kernel version 2.4.18 or higher. This option will be hidden if the current CPU does not support Hyper-Threading Technology.

## Chipset Configuration:

AMIBIOS SETUP UTILITY - VERSION 3.31a		
Advanced		
Chipset Configuration		[ Setup Help ]
AGP Aperture Size	64MB	<Enter> to select the size of mapped memory for graphics data.
ICH Delayed Transaction	Disabled	
USB Controller	Enabled	
USB Device Legacy Support	Disabled	
CPU Thermal Throttling	Disabled	
DRAM Write Throttling	Disabled	
AGP / PCI Frequency	Auto	
***** DRAM Timing *****		
SDRAM CAS Latency	Auto	
Configure SDRAM Timing by SPD	Disabled	
SDRAM RAS# Precharge	3 Clocks	
SDRAM RAS# to CAS# Delay	3 Clocks	
SDRAM Precharge Delay	7 Clocks	
F1:Help	↑↓:Select Item	+/-:Change Values
Esc:Previous Menu		Enter:Select   ▶Sub-Menu
		F9:Setup Defaults
		F10:Save & Exit

**AGP Aperture Size:** It refers to a section of the PCI memory address range used for graphics memory. We recommend that you leave this field at the default value unless your AGP card requires other sizes.

**ICH Delayed Transaction:** Select [Enabled] will enable delayed transactions for internal register, FWH, and LPC interface accesses.

**USB Controller:** Use this to enable or disable the use of USB controller.

**USB Device Legacy Support:** Use this to enable or disable support to emulate legacy I/O devices such as mouse, keyboard,... etc.

**CPU Thermal Throttling:** Select [Enabled] will enable P4 thermal control circuit to keep CPU from overheated.

**DRAM Write Throttling:** Select [Enabled] will reduce the temperature of North Bridge and DRAM. However, it will decrease the memory writing throughput.

**AGP/PCI Frequency:** The default value is [Auto], or you may select among other four sets of configuration options as the AGP/PCI frequency. Configuration options: [Auto], [67.2MHz, 33.6MHz], [72.0MHz, 36.0MHz], [64.0MHz, 32.0MHz], [76.0MHz, 38.4MHz].

### SDRAM CAS Latency:

This parameter controls the latency between the read command and the time the data available.

---

**Configure SDRAM Timing by SPD:** Select [Enabled] will configure the following 3 items by the contents in the SPD (Serial Presence Detect) device.

**SDRAM RAS# Precharge:**

This controls the idle clocks after a precharge command is issued.


**SDRAM RAS# to CAS# Delay:**

This controls the latency between the SDRAM active command and the read / write command.

**SDRAM Precharge Delay:**

This controls the number of DRAM clocks for RAS minimum.

**Resource Configuration:**



**PCI Latency Timer (PCI Clocks):** The default is 32. We recommend you to keep the default value unless your PCI expansion cards' specifications require other settings.

**Primary Graphics Adapter:** Select PCI or AGP as the primary graphics adapter.



## Peripheral Configuration:

AMIBIOS SETUP UTILITY - VERSION 3.31a	
Advanced	
Peripheral Configuration	[ Setup Help ]
OnBoard FDC	Auto
OnBoard Serial Port	Auto
OnBoard Infrared Port	Disabled
OnBoard Parallel Port	Auto
Parallel Port Mode	ECP + EPP
EPP Version	1.9
Parallel Port IRQ	Auto
Parallel Port DMA Channel	Auto
OnBoard Midi Port	Disabled
Midi IRQ Select	5
OnBoard Game Port	200H
OnBoard IDE	Both
OnBoard LAN	Enabled
OnBoard AC'97 Audio	Auto

F1: Help	F11: Select Item	+/-: Change Values	F9: Setup Defaults
Esc: Previous Menu		Enter: Select	F10: Save & Exit
		▶ Sub-Menu	

**OnBoard FDC:** You may select [Auto], [Disabled], or [Enabled] for the on-board floppy drive controller.

**OnBoard Serial Port:** Use this to set addresses for the on-board serial ports or disable serial ports.

Configuration options: [Auto], [Disabled], [3F8 / IRQ4 / COM1], [2F8 / IRQ3 / COM2], [3E8 / IRQ4 / COM3], [2E8 / IRQ3 / COM4].

**OnBoard Infrared Port:** You may select [Auto] for the on-board infrared port feature, which will enable this feature if the infrared module is installed.

Or you may disable the feature by selecting [Disabled]

**OnBoard Parallel Port:** Use this option to select Parallel Port address or disable the on-board Parallel Port.

Configuration options: [Auto], [Disabled], [378], [278].

**Parallel Port Mode:** Set the operation mode of the parallel port.

The default value is [ECP+EPP]. If this option is set to [ECP+EPP], it will show the EPP version in the following item, "EPP Version".

**OnBoard Midi Port:** Select address for the on-board Midi Port or disable it.

Configuration options: [Disabled], [330], [300], [310], [320].

**Midi IRQ Select:** Use this to select Midi IRQ.

Configuration options: [3], [4], [5], [7], [10], [11].

**OnBoard Game Port:** Select address for the on-board Game Port or disable it.

Configuration options: [200H], [208H], [Disabled].

**OnBoard IDE:** You may enable either the primary IDE channel or the secondary IDE channel. Or you may enable both the primary and the secondary IDE channels by selecting [Both]. Set to [Disabled] will disable the both.

Configuration options: [Disabled], [Primary], [Secondary], [Both].

---

**OnBoard LAN:** This allows you to enable or disable the on-board LAN feature.

**OnBoard AC'97 Audio:** Select [Enabled], [Auto] or [Disabled] for the on-board AC'97 Audio feature.

**System Hardware Monitor:** You may check the status of the hardware on your system. It allows you to monitor the parameters for CPU temperature, Motherboard temperature, CPU fan speed, and critical voltage.

AMIBIOS SETUP UTILITY - VERSION 3.31a	
Advanced	
System Hardware Monitor	[ Setup Help ]
CPU Temperature	39°C / 102°F
M/B Temperature	31°C / 87°F
CPU Fan Speed	4197 RPM
Chassis Fan Speed	0 RPM
Vcore	1.504 V
+ 3.30V	3.280 V
+ 5.00V	4.865 V
+12.00V	12.045 V

F1:Help      ↑:Select Item      +/-:Change Values      F9:Setup Defaults  
Esc:Previous Menu      Enter:Select      ▶Sub-Menu      F10:Save & Exit

## 2. Security Setup Menu

AMIBIOS SETUP UTILITY - VERSION 3.31a			
Main	Advanced	Security	Power Boot Exit
Supervisor Password Is	Clear		[ Setup Help ]
User Password Is	Clear		<Enter> to enable or disable the quick boot mode.
Set Supervisor Password	[ Enter ]		
Set User Password	[ Enter ]		
Password Check	Setup		
F1:Help Esc:Exit	↑↓:Select Item ←→:Select Menu	+/-:Change Values Enter:Select	F9:Setup Defaults F10:Save & Exit

**Supervisor Password Is:** This field shows the status of the Supervisor Password.

**[Clear]:** No password has been set.

**[Set]:** Supervisor password has been set.

**User Password Is:** This field shows the status of the User Password.

**[Clear]:** No password has been set.


**[Set]:** User password has been set.

**Set Supervisor Password:** Press <Enter> to set Supervisor Password. Valid password can be a 1 to 6 alphanumeric characters combination. If you already have a password, you must enter your current password first in order to create a new password.

**Set User Password:** Press <Enter> to set User Password. Valid password can be a 1 to 6 alphanumeric characters combination. If you already have a password, you must enter your current password first in order to create a new password.

**Password Check:** Select the check point for "Password Check". Configuration options: [Setup], [Always]. If [Setup] option is selected, the "Password Check" is performed before BIOS setup. If [Always] option is selected, the "Password Check" is performed before both boot-up and BIOS setup.

### 3. Power Setup Menu



**Suspend To RAM:** This field allows you to select whether to auto-detect or disable the ACPI Suspend-to-RAM feature. Select [Auto] will enable this feature if the system supports it.

**Repost Video on STR Resume:** This feature allows you to repost video on STR resume. It is recommended to enable this feature under Microsoft® Windows® 98 / ME.

**Restore on AC/Power Loss:** This allows you to set the power state after an unexpected AC/power loss. If [Power Off] is selected, the AC/power remains off when the power recovers. If [Power On] is selected, the AC/power resumes and the system starts to boot up when the power recovers.

**Ring-In Power On:** Use this to enable or disable Ring-in signals to turn on the system from the power-soft-off mode.

**PCI Devices Power On:** Use this to enable or disable PCI devices to turn on the system from the power-soft-off mode.

**PS/2 Keyboard Power On:** You may select [Any Key] to enable PS/2 keyboard to turn on the system from the power-soft-off mode. Or you may disable this feature by selecting [Disabled].

**RTC Alarm Power On:** Use this to enable or disable RTC (Real Time Clock) to power on the system. If [Enable] is selected, you must fill the RTC Alarm Date / Hour / Minute / Second sub-fields with the actual wake up time you desire.

---

## 4. Boot Setup Menu

AMIBIOS SETUP UTILITY - VERSION 3.31a					
Main	Advanced	Security	Power	Boot	Exit
Quick Boot Mode	Enabled	[ Setup Help ]			
Boot Up Num-Lock	On	<Enter> to enable or			
Boot To OS/2	No	disable the quick boot			
Boot From Network	Disabled	mode.			
▶ Boot Device Priority					
F1:Help	↑:Select Item	+/-:Change Values	F9:Setup Defaults		
Esc:Exit	→:Select Menu	Enter>Select	▶Sub-Menu F10:Save & Exit		

**Quick Boot Mode:** Enable this mode will speed up the boot-up routine by skipping memory retestings.

**Boot Up Num-Lock:** Select [On] to activate the Numeric Lock function automatically after boot-up.


**Boot To OS/2:** Select [Yes] to enable boot-up to OS/2 operating system.

**Boot From Network:** Use this to enable or disable “boot from network” feature.

**Boot Device Priority:** This allows you to set the boot device priority.

---

## 5. Exit Menu



**Exit Saving Changes:** After you enter the sub-menu, the message “Save current settings and exit” will appear. If you press <ENTER>, it will save the current settings and exit the BIOS SETUP Utility.

**Exit Discarding Changes:** After you enter the submenu, the message “Quit without saving changes” will appear. If you press <ENTER>, you will exit the BIOS Setup Utility without making any changes to the settings.

**Load Default Settings:** After you enter the submenu, the message “Load default settings” will appear. If you press <Enter>, it will load the default values for all the setup configuration.

**Discard Changes:** After you enter the sub-menu, the message “Load setup original values” will appear. If you press <ENTER>, original values will be restored and all changes are discarded.