

FCC Compliance Statement:

<p align="center">DECLARATION OF CONFORMITY Per FCC Part 2 Section 2.107(a)</p> <p align="center">FC</p> <p>Responsible Party Name: G.B.T. INC.</p> <p align="center">Address: 18365 Valley Blvd., Suite#A LA Puente, CA 91744</p> <p align="center">Phone/Fax No: (818) 854-9338 / (818) 854-9339</p> <p>hereby declares that the product</p> <p>Product Name: Mother Board</p> <p>Model Number: GA-6LMM</p> <p>Conforms to the following specifications:</p> <p>FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109(a), Class B Digital Device.</p> <p>Supplementary Information:</p> <p><small>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any interference received, including that may cause undesired operation.</small></p> <p>Representative Person's Name: <u>ERIC LIU</u></p> <p>Signature: <u>Eric Liu</u></p> <p>Date: <u>Feb. 20, 2001</u></p>

This equipment has been tested and found to comply with limits for a Class B digital device , pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Move the equipment away from the receiver
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for additional suggestions

You are cautioned that any change or modifications to the equipment not expressly approve by the party responsible for compliance could void Your authority to operate such equipment.

This device complies with Part 15 of the FCC Rules. Operation is subjected to the following two conditions 1) this device may not cause harmful interference and 2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

We, Manufacturer/Importer
(full address)

G.B.T. Technology Trading GmbH
Ausschlagler Weg 41, 1F, 20537 Hamburg, Germany

declare that the product
(description of the apparatus, system, installation to which it refers)

Mother Board
GA-6PMM

is in conformity with
(reference to the specification under which conformity is declared)
in accordance with 89/336 EEC-EMC Directive

- | | | | |
|---|--|--|--|
| <input type="checkbox"/> EN 55011 | Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM high frequency equipment | <input type="checkbox"/> EN 61000-3-2*
<input checked="" type="checkbox"/> EN60555-2 | Disturbances in supply systems caused by household appliances and similar electrical equipment "Harmonics" |
| <input type="checkbox"/> EN55013 | Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment | <input type="checkbox"/> EN61000-3-3*
<input checked="" type="checkbox"/> EN60555-3 | Disturbances in supply systems caused by household appliances and similar electrical equipment "Voltage fluctuations" |
| <input type="checkbox"/> EN 55014 | Limits and methods of measurement of radio disturbance characteristics of household electrical appliances, portable tools and similar electrical apparatus | <input checked="" type="checkbox"/> EN 50081-1
<input checked="" type="checkbox"/> EN 50082-1 | Generic emission standard Part 1: Residual, commercial and light industry
Generic immunity standard Part 1: Residual, commercial and light industry |
| <input type="checkbox"/> EN 55015 | Limits and methods of measurement of radio disturbance characteristics of fluorescent lamps and luminaries | <input type="checkbox"/> EN 55081-2 | Generic emission standard Part 2: Industrial environment |
| <input type="checkbox"/> EN 55020 | Immunity from radio interference of broadcast receivers and associated equipment | <input type="checkbox"/> EN 55082-2 | Generic immunity standard Part 2: Industrial environment |
| <input checked="" type="checkbox"/> EN 55022 | Limits and methods of measurement of radio disturbance characteristics of information technology equipment | <input type="checkbox"/> ENV 55104 | Immunity requirements for household appliances tools and similar apparatus |
| <input type="checkbox"/> DIN VDE 0855
<input type="checkbox"/> part 10
<input type="checkbox"/> part 12 | Cabled distribution systems; Equipment for receiving and/or distribution from sound and television signals | <input type="checkbox"/> EN 50091- 2 | EMC requirements for uninterruptible power systems (UPS) |

CE marking



(EC conformity marking)

The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 73/23 EEC

- | | | | |
|-----------------------------------|---|-------------------------------------|---|
| <input type="checkbox"/> EN 60065 | Safety requirements for mains operated electronic and related apparatus for household and similar general use | <input type="checkbox"/> EN 60950 | Safety for information technology equipment including electrical business equipment |
| <input type="checkbox"/> EN 60335 | Safety of household and similar electrical appliances | <input type="checkbox"/> EN 50091-1 | General and Safety requirements for uninterruptible power systems (UPS) |

Manufacturer/Importer

Signature : Rex Lin
Name : Rex Lin

(Stamp)

Date : Feb. 20, 2001

6PMM Series
Socket 370 Processor Motherboard

USER'S MANUAL

Socket 370 Processor Motherboard
REV. 3.2 Third Edition
R-32-03-010622
12ME-6PMM-3203

How This Manual Is Organized

This manual is divided into the following sections:

1) Revision History	Manual revision information
2) Item Checklist	Product item list
3) Features	Product information & specification
4) Installation Guide	Instructions on CPU & Memory Installation
5) Performance & Block Diagram	Product performance & block diagram
6) Suspend to RAM	Instructions STR installation
7) BIOS Setup	Instructions on setting up the BIOS software
8) Technical Support /RMA Sheet	Document equipment used for after sales service
9) Appendix	General reference

Table Of Content

Revision History	P.1
Item Checklist	P.2
Summary of Features	P.3
6PMM Series Motherboard Layout	P.5
Installation Guide	P. 6
Page Index for Connectors / Panel and Jumper Definition	P.19
Performance List	P.35
Block Diagram	P.36
Suspend to RAM Installation	P.37
@BIOS Introduction	P.43
Easy Tune III™ Introduction	P.44
Page Index for BIOS Setup	P.46
Technical Support /RMA Sheet	P.73
Appendix	P.74

Revision History

Revision	Revision Note	Date
3.1	Initial release of the 6PMM Series motherboard user's manual.	Oct.2000
3.2	Initial release of the 6PMM Series motherboard user's manual.	Dec.2000
3.2	Second release of the 6PMM Series motherboard user's manual.	Feb.2001
3.3	Third release of the 6PMM Series motherboard user's manual.	Jun.2001

The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein. Third-party brands and names are the property of their respective owners.

Item Checklist

- The 6PMM Series motherboard
- Cable for IDE / floppy device
- Diskettes or CD (TUCD) for motherboard driver & utility
- 6PMM Series user's manual

Features Summary


Form Factor	<ul style="list-style-type: none"> 24.3 cm x 23.4 cm Micro ATX size form factor, 4 layers PCB.
Motherboard	<ul style="list-style-type: none"> 6PMM Series includes 6PMM, 6PMM-L
CPU	<ul style="list-style-type: none"> Socket 370 processor <ul style="list-style-type: none"> Intel Pentium® III 100/133MHz FSB, FC-PGA Intel Celeron™ 66MHz FSB, FC-PGA VIA Cyrix® III 100 MHz FSB, CPGA (Please make sure your CPU is mass production version) L2 cache in CPU (Depend on CPU)
Chipset	<ul style="list-style-type: none"> VT8605 (PM133) VT82C686B
Clock Generator	<ul style="list-style-type: none"> ICS 9248DF-39 66/100/133 MHz system bus speeds (PCI 33MHz)
Memory	<ul style="list-style-type: none"> 2 168-pin DIMM sockets. Supports PC-100 / PC-133 SDRAM and VCM SDRAM Supports up to 1.0GB DRAM Supports only 3.3V SDRAM DIMM
I/O Control	<ul style="list-style-type: none"> VT82C686B
Slots	<ul style="list-style-type: none"> 1 AGP slot supports 4X mode & AGP 2.0 compliant 3 PCI slot supports 33MHz & PCI 2.2 compliant 1 AMR slot
On-Board IDE	<ul style="list-style-type: none"> 2 IDE bus master (UDMA 33/ ATA 66 / ATA100)IDE ports for up to 4 ATAPI devices Supports PIO mode 3, 4 (UDMA 33/ATA 66)IDE & ATAPI CD-ROM
On-Board Peripherals	<ul style="list-style-type: none"> 1 floppy port supports 2 FDD with 360K, 720K,1.2M, 1.44M and 2.88M bytes 1 parallel port supports Normal/EPP/ECP mode 2 serial ports (COM 1 and COM 2) 4 USB ports
Hardware Monitor	<ul style="list-style-type: none"> CPU / System fan revolution detect CPU / System temperature detect System voltage detect (Vcore,3.3V,+5V,+12V) CPU overheat shutdown detect ACPI Shut Down Temperature detect
PS/2 Connector	<ul style="list-style-type: none"> PS/2® Keyboard interface and PS/2® Mouse interface
BIOS	<ul style="list-style-type: none"> Licensed AMI BIOS, 2M bit flash ROM

To be continued...

Features Summary

On-Board LAN	<ul style="list-style-type: none">• Build in RTL8139C (Optional)
On-Board Sound	<ul style="list-style-type: none">• AC'97 CODEC• Line In/Line Out/Mic In/CD In/TEL/Game Port
On-Board VGA	<ul style="list-style-type: none">• Build S3 Savage4 (86C370) in VT8605• Support shared memory architecture`
Additional Features	<ul style="list-style-type: none">• Includes 3 fan power connectors.• Poly fuse for keyboard over-current protection• Support STR (Suspend-To-RAM) function• Support Wake-On LAN (WOL)• Support internal / external Modem wake up.

6PMM Motherboard Layout



Installation Guide

Getting Started



WARNING!

Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

1. Unplug your computer when working on the inside.
2. Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
3. Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.


Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

6PMM Series Motherboard

To set up your computer, you must complete the following steps:

- ▶ Step 1 - Set system jumpers
- ▶ Step 2- Install the Central Processing Unit (CPU)
- ▶ Step 3-Install memory modules
- ▶ Step 4-Install expansion cards
- ▶ Step 5-Connect ribbon cables, cabinet wires, and power supply
- ▶ Step 6-Set up BIOS software
- ▶ Step 7-Install supporting software tools




CPU Installation


Please make sure the CPU type and speed is supported by your motherboard.




CPU Top View



CPU Bottom View



1. Pull the lever out and lift it up.



2. The notched corner should point toward the end of the lever. The CPU will only fit in the orientation as shown.

CPU Heat Sink Installation:

Beware: Please check that the heat sink is in good contact with the CPU before you turn on your system. **Poor contact will cause over heat with might cause damage to your processor!**




3. Align CPU and insert it

(Please refer to your heatsink installation manual for application of thermal grease to provide better heat conduction between your CPU and heatsink.)




4. Use compliant fan approved by Intel.



5. Hook one end of the cooler bracket to the CPU socket.

6. Hook the other end of the cooler bracket to the CPU socket.



 (Please refer to the cooler's installation manual for detailed installation steps)

CPU Speed Setup

The system bus speed is selectable at 66,100,133MHz and Auto. The user can select the system bus speed (**SW1**) and change the DIP switch (**SW2**) selection to set up the CPU speed for 500 – 1G Hz processor.

Set System Bus Speed

O : ON, X : OFF


SW1:CPU (MHz)	PCI(MHz)	1	2	3	4	5	6
Auto	33.3	X	X	X	X	O	O
66	33.3	O	O	X	X	X	X
100	33.3	O	X	X	X	X	X
133	33.3	X	X	X	X	X	X

The CPU speed must match with the frequency ratio. It will cause system hanging up if the frequency ratio is higher than that of CPU.

SW2:FREQ. RATIO	DIP SWITCH			
	1	2	3	4
X 3	O	X	O	O
X 3.5	X	X	O	O
X 4	O	O	X	O
X 4.5	X	O	X	O
X 5	O	X	X	O
X 5.5	X	X	X	O
X 6	O	O	O	X
X 6.5	X	O	O	X
X 7	O	X	O	X
X 7.5	X	X	O	X
X 8	O	O	X	X
X 8.5	O	X	O	O
X 9	X	X	O	O
X 9.5	X	O	O	O
X 10	X	O	X	X
X 10.5	O	O	X	O
X11	O	X	X	X
X11.5	X	O	X	O
X12	O	X	X	O
X13	X	X	X	O
X14	O	O	O	X
X15	X	O	O	X
X16	O	X	O	X

● Intel Processor all have locked Frequency Multiple, so you can not change the CPU Frequency Multiple.


☛ For Auto Jumper Setting:




★ Note:

1. If you use 66/100/133 MHz CPU, We recommend you to setup your system speed to "Auto" value.


1. Celeron™ 533/ 66 MHz FSB




2. Celeron™ 566/ 66 MHz FSB




3. Celeron™ 600/ 66 MHz FSB




4. Celeron™ 633/ 66 MHz FSB




5. Celeron™ 667/ 66 MHz FSB




6. Celeron™ 700/ 66 MHz FSB




7. Cyrix® III 550/ 100MHz FSB (Optional)




8. Cyrix® III 600 / 100 MHz FSB (Optional)




9. Pentium® !!! 500/100MHz FSB




10. Pentium® !!! 550/100MHz FSB




11. Pentium® !!! 600/100MHz FSB




12. Pentium® !!! 650/100MHz FSB




13. Pentium® !!! 700/100MHz FSB




14. Pentium® !!! 750/100MHz FSB




15. Pentium® !!! 800/100MHz FSB




16. Pentium® !!! 850/100MHz FSB




17. Pentium® !!! 533/133MHz FSB




18. Pentium® !!! 600/133 MHz FSB




19. Pentium® !!! 667/133MHz FSB




20. Pentium® !!! 733/133MHz FSB




21. Pentium® !!! 800/133MHz FSB




22. Pentium® !!! 866/133MHz FSB



23. Pentium® !!! 933/133MHz FSB




24. Pentium® !!! 1G Hz /133MHz FSB





Memory Installation

The motherboard has 2 dual inline memory module (DIMM) sockets support 4 banks. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM Slot .The DIMM module can only fit in one direction due to the two notch. Memory size can vary between sockets.



SDRAM




1. The DIMM slot has two notch, so the DIMM memory module can only fit in one direction.
 2. Insert the DIMM memory module vertically into the DIMM slot. Then push it down.
 3. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module.
-  Reverse the installation steps when you wish to remove the DIMM module.

Install memory in any combination table:

DIMM	168-pin SDRAM DIMM Modules	
DIMM 1	Supports 16 / 32 / 64 / 128 / 256 / 512 MB	X 1 pcs
DIMM 2	Supports 16 / 32 / 64 / 128 / 256 / 512 MB	X 1 pcs



★Total System Memory (Max 1GB)

6PMM Series Motherboard

 Page Index for CPU Speed Setup / Connectors / Panel and Jumper Definition	Page
CPU Speed Setup	P.7
Connectors	P.20
Game & Audio Port	P.15
COM A / COMB / VGA / LPT Port	P.15
USB 1 & LAN Connector	P.16
PS/2 Keyboard & PS/2 Mouse Connector	P.16
USB 2 Front USB Connector	P.17
JP1 (CPU Fan Connector)	P.17
JP3 (Power Fan Connector)	P.18
JP4 (System Fan Connector)	P.18
ATX Power	P.19
Floppy Port	P.19
IDE 1(Primary)/ IDE 2(Secondary) Port	P.20
J7 (TEL)	P.20
J8 (CD Audio Line In)	P.21
J2 (IR)	P.21
J4 (Modem Ring On)	P.22
J5 (Wake On LAN)	P.22
JP12 / LED1 (STR LED Connector & DIMM LED)	P.23
JP20 (Front Audio)	P.23
Panel and Jumper Definition	P.24
J3 (2x11 Pins Jumper)	P.24
JP5 (Clear CMOS Function)	P.25
JP6 (Case Open)	P.25
JP7 (USB Device Wake Up Selection)	P.26
JP8 (BIOS Write Protection)	P.26
JP11 (STR Function Selection)	P.27
JP10 (Over Voltage CPU Speed Up)	P.27
JP9 (Onboard LAN Function)	P.28
JP21 (Front MIC)	P.28
JP16/JP17/JP18 (Onboard AC97& AMR Select)	P.29
BAT1(Battery)	P.29

Connectors




Game & Audio Port



Please note:

This motherboard supports standard audio port and game port. After install onboard audio driver, you may connector speaker to line out jack, micro phone to MIC in jack. Device like CD-ROM , walkman etc can be connected to line-in jack

COM A / COM B / VGA / LPT Port





Please note:

This mainboard supports 1 standard COM port, 1 VGA port and 1 LPT port. Device like printer can be connected to LPT port ; mouse and modem etc can be connected to COM ports.

USB1 & LAN : USB1 Connector & LAN Connector

(LAN Connector is Optional)




Pin No.	Definition
1	USB V0
2	USB D0-
3	USB D0+
4	GND
5	USB V1
6	USB D1-
7	USB D1+
8	GND

G – Green LED
(LAN Link LED)
Y – Yellow LED
(LAN Active LED)




Please note: Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker..etc. have a standard USB interface. Also make sure your OS (Win 95 w/ USB supperment, Win98, Windows 2000, Windows ME, Win NT w/ SP 6) supports USB controller. If your OS does not support USB controller, please contact OS venders for possible patch or driver upgrade. For more information please contact your OS or device(s) venders.

PS/2 Keyboard & PS/2 Mouse Connector



PS/2 Mouse




PS/2 Keyboard

PS/2 Mouse/ Keyboard	
Pin No.	Definition
1	Data
2	NC
3	GND
4	VCC(+5V)
5	Clock
6	NC



Please note: This mainboard supports standard PS/2 keyboard and PS/2 mouse interface connector.

USB 2 Front USB Connector




Pin No.	Definition
1	5V-SB
2	GND
3	USB D2-
4	NC
5	USB D2+
6	USB D3+
7	NC
8	USB D3-
9	GND
10	5V-SB



Please note:

Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.

JP1: CPU Fan




Pin No.	Definition
1	Control
2	+12V
3	SENSE




Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating.

JP3: Power Fan





Pin No.	Definition
1	Control
2	+12V
3	NC

JP4: System Fan



Pin No.	Definition
1	Control
2	+12V
3	SENSE

ATX Power




Pin No.	Definition
3,5,7,13,15-17	GND
1,2,11	3.3V
4,6,19,20	VCC
10	+12V
12	-12V
18	-5V
8	Power Good
9	5V SB (Stand by+5V)
14	PS-ON (Soft On/Off)



Please note:


AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

Floppy Port




Red Line

IDE1(Primary), IDE2(Secondary) Port





IDE 1 IDE 2





Red Line

J7 : TEL: The connector is for Modem with internal voice connector




Pin No.	Definition
1	Signal-In
2	GND
3	GND
4	Signal-Out

J8:CD Audio Line In



Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

J2:IR




Pin No.	Definition
1	VCC (+5V)
2	NC
3	IR Data Input
4	GND
5	IR Data Output

**Please note:**



Be careful with the polarity of the IR connector while you connect the IR.
Please contact your nearest dealer for optional IR device

J4: Internal Modem Card Wake Up




Pin No.	Definition
1	Signal
2	GND

J5: Wake On LAN



Pin No.	Definition
1	+5V SB
2	GND
3	Signal

JP12 : STR LED Connector & DIMM LED





STR LED Connector External.

**Please note:**

Do not remove memory modules while DIMM LED is on. It might cause short or other unexpected damages due to the 3.3V stand by voltage. Remove memory modules only when STR function is disabled by jumper and AC Power cord is disconnected.

JP20: Front Audio



PIN NO.	Definition
1	Incase speaker (R)
2	Incase speaker (L)
3, 4,5,6,10,15	GND
7	+12V
8,16	NC
9	MIC
11	Front Audio (R)
13	Front Audio (L)
12	Rear Audio (R)
14	Rear Audio (L)





Please note : If you want to use "Front Audio" connector, you must move 11-12,13-14 Jumper.

In order to utilize the front audio header, your chassis must have front audio connector. Also please make sure the pin assignment on the cable is the same as the pin assignment on the MB header. To find out if the chassis you are buying support front audio connector, please contact your dealer.


Panel and Jumper Definition

J3 : 2x11 Pins Jumper



GN (Green Switch)	Open: Normal Operation Close: Entering Green Mode
GD (Green LED)	Pin 1: LED anode(+) Pin 2: LED cathode(-)
HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+) Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+) Pin 2- Pin 3: NC Pin 4: Data(-)
RE (Reset Switch)	Open: Normal Operation Close: Reset Hardware System
P+P-P-(Power LED)	Pin 1: LED anode(+) Pin 2: LED cathode(-) Pin 3: LED cathode(-)
PW (Soft Power Connector)	Open: Normal Operation Close: Power On/Off

JP5 : Clear CMOS Function



Normal
(Default)




Clear CMOS

Pin No.	Definition
1-2 close	Clear CMOS
2-3 close	Normal (Default)




Please note, You may clear the CMOS data to its default values by this jumper

JP6 : Case Open



Pin No.	Definition
1	Signal
2	GND

JP7 :USB Device Wake up Selection



1

**Normal
(Default)**



1

Enable


Pin No.	Definition
1-2 Close	Normal (Default)
2-3 Close	USB Device Wake up



Please note, To use "USB Device Wakeup" function, set BIOS setting "USB Dev Wake up from S3" to ENABLED and enable jumpers JP7&JP11. To prevent user confusion.

*(Power on the computer and as soon as memory counting starts, press . You will enter BIOS Setup. Select the item "POWER MANAGEMENT SETUP", then select "USB Dev Wake up from S3". Remember to save the setting by pressing "ESC" and choose the "SAVE & EXIT SETUP" option.)

JP8 : BIOS Write Protection



1

**Normal
(Default)**



1



**Write
Protection**

Pin No.	Definition
1-2close	Write Protection
2-3close	Normal (Default)



Please note, To flash/upgrade BIOS on this MB JP8 must be set to 2-3 close. We recommend JP8 to be set to "1-2 close", whenever user does not need to flash/upgrade the BIOS.




JP11: STR Function Selection



Pin No.	Definition
1-2 close	STR Enabled
2-3 close	STR Disabled (Default)


JP10 : Over Voltage CPU Speed Up (Magic Booster)

(When JP10 set "Pin1-2" close , CPU Voltage is rising 10%)



Pin No.	Definition
1-2 close	Over CPU Voltage
2-3 close	Normal (Default)

JP9: Onboard LAN Function (Optional)



**Enabled
(Default)**



Disabled


Pin No.	Definition
1-2 close	Onboard LAN Enabled (Default)
2-3 close	Onboard LAN Disabled



Please note,

This MB supports optional LAN chip. If the MB has optional LAN chip the user can enable the LAN function by setting the JP9 to 1-2, user can disable the optional LAN function by setting the JP9 to 2-3. JP9 will have any effect if the board does not have optional LAN chip.

JP21: Front MIC (Optional)




**Disable
(Default)**



Enable

Pin No.	Definition
1-2close	Disable (Default)
2-3close	Enable

JP16/JP17/JP18 : Onboard AC97& AMR (Primary or Secondary)
 Select (Optional) (**AMR**→ **Audio Modem Riser**)




Jumper Function	JP17	JP18	JP16
Only AC97	1-2 Close	1-2 Close	2-3 Close
Only AMR (Primary)	3-4 Close	3-4 Close	2-3 Close
AC97+MR (Secondary) (Default)	1-2 3-4 Close	1-2 Close	1-2 Close



Please note, This MB supports AMR slot, you can look up the table above to choose the appropriate AMR card for your board.

BAT1 : Battery



CAUTION

- ☞ Danger of explosion if battery is incorrectly replaced.
- ☞ Replace only with the same or equivalent type recommended by the manufacturer.
- ☞ Dispose of used batteries according to the manufacturer's instructions.

Performance List


The following performance data list is the testing results of some popular benchmark testing programs.

These data are just referred by users, and there is no responsibility for different testing data values gotten by users. (The different Hardware & Software configuration will result in different benchmark testing results.)

- CPU Intel® Coppermine 1G Hz , Intel® Coppermine 850MHz
Intel® Celeron® 700MHz , VIA Cyrix III 600MHz
- DRAM (256 x 1) MB SDRAM (Mosel V54C328804VCT75)
- CACHE SIZE 128KB included in Celeron, 256KB included in Coppermine
- DISPLAY Onboard S3 Savage4, 8MB Display cache
- STORAGE Onboard IDE (Quantum KA13600AT)
- O.S. Windows NT™ 4.0 SP6a
- DRIVER Display Driver at 1024 x 768 x 24bits colors x 75Hz.
VIA ACPI 4 in 1 V4.23A

Processor	Intel Pentium® !!! Socket 370		Intel Celeron™ Socket 370	VIA Cyrix III Socket 370
	Coppermine 1000(133*7.5)	Coppermine 850(100*8.5)	Celeron 700(66*10.5)	Cyrix III 600 (133*4.5)
Winbench 99				
CPU mark 99	99	70.7	44.6	25.4
FPU Winmark 99	5330	4530	3730	992
Business Disk Winmark 99	5410	5800	5380	4730
Hi-End Disk Winmark 99	13400	14200	13000	13100
Business Graphics Winmark 99	181	171	132	110
Hi-End Graphics Winmark 99	551	472	359	226
Winstone 99				
Business Winstone 99	40.6	38.2	29.7	25.5
Hi-End Winstone 99	51	46.1	35.3	18.6

Block Diagram



Suspend To RAM Installation

A.1 Introduce STR function:

Suspend-to-RAM (STR) is a Windows 98 ACPI sleep mode function. When recovering from STR (S3) sleep mode, the system is able, in just a few seconds, to retrieve the last "state" of the system before it went to sleep and recover to that state. The "state" is stored in memory (RAM) before the system goes to sleep. During STR sleep mode, your system uses only enough energy to maintain critical information and system functions, primarily the system state and the ability to recognize various "wake up" triggers or signals, respectively.

A.2 STR function Installation

Please use the following steps to complete the STR function installation.

Step-By-Step Setup

Step 1:

To utilize the STR function, the system must be in Windows 98 ACPI mode.



Putting Windows 98 into ACPI mode is fairly easy.

Setup with Windows 98 CD:

- A. Insert the Windows 98 CD into your CD-ROM drive, select Start, and then Run.
- B. Type (without quotes) "**D:\setup**" in the window provided. Hit the enter key or click OK.
- C. After setup completes, remove the CD, and reboot your system
(This manual assumes that your CD-ROM device drive letter is D:).

Step 2:

(If you want to use STR Function, please set jumper JP11 Pin 1-2 Closed.)



Pin No.	Definition
1-2 close	STR Enabled
2-3 close	STR Disabled

Step 3:

Power on the computer and as soon as memory counting starts, press . You will enter BIOS Setup. Select the item **"POWER MANAGEMENT SETUP"**, then select **"ACPI Sleep Type : S3 / STR"**. Remember to save the settings by pressing "ESC" and choose the **"SAVE & EXIT SETUP"** option.

Congratulation! You have completed the installation and now can use the STR function.


A.3 How to put your system into STR mode?

There are two ways to accomplish this:


1. Choose the "Stand by" item in the "Shut Down Windows" area.
 - A. Press the "Start" button and then select "Shut Down"




- B. Choose the "Stand by" item and press "OK"




2. Define the system "power on" button to initiate STR sleep mode:
 - A. Double click "My Computer" and then "Control Panel"



- B. Double click the " Power Management" item.



C. Select the "Advanced" tab and "Standby" mode in Power Buttons.



D. Restart your computer to complete setup.

Now when you want to enter STR sleep mode, just momentarily press the "Power on" button.


A.4 How to recover from the STR sleep mode?

There are five ways to "wake up" the system:

1. Press the "Power On" button.
2. Use the "Resume by Alarm" function.
3. Use the "Modem Ring On" function.
4. Use the "Wake On LAN" function.
5. Use the "USB Device Wake Up" function.

A.5 Notices :

1. In order for STR to function properly, several hardware and software requirements must be satisfied:
 - A. Your ATX power supply must comply with the ATX 2.01 specification (provide more than 720 mA 5V Stand-By current).
 - B. Your SDRAM must be PC-100 compliant.
2. Jumper JP12 is provided to connect to the STR LED in your system chassis. [Your chassis may not provide this feature.] The STR LED will be illuminated when your system is in STR sleep mode.



STR LED Connector External.



DIMM LED

@ BIOS Introduction

Gigabyte announces @ BIOS Windows BIOS live update utility



Have you ever updated BIOS by yourself? Or like many other people, you just know what BIOS is, but always hesitate to update it? Because you think updating newest BIOS is unnecessary and actually you don't know how to update it.

Maybe not like others, you are very experienced in BIOS updating and spend quite a lot of time to do it. But of course you don't like to do it too much. First, download different BIOS from website and then switch the operating system to DOS mode. Secondly, use different flash utility to update BIOS. The above process is not a interesting job. Besides, always be carefully to store the BIOS source code correctly in your disks as if you update the wrong BIOS, it will be a nightmare.

Certainly, you wonder why motherboard vendors could not just do something right to save your time and effort and save you from the lousy BIOS updating work? Here it comes! Now Gigabyte announces @BIOS--the first Windows BIOS live update utility. This is a smart BIOS update software. It could help you to download the BIOS from internet and update it. Not like the other BIOS update software, it's a Windows utility. With the help of '@BIOS', BIOS updating is no more than a click.

Besides, no matter which mainboard you are using, if it's a Gigabyte's product*, @BIOS help you to maintain the BIOS. This utility could detect your correct mainboard model and help you to choose the BIOS accordingly. It then downloads the BIOS from the nearest Gigabyte ftp site automatically. There are several different choices; you could use "Internet Update" to download and update your BIOS directly. Or you may want to keep a backup for your current BIOS, just choose "Save Current BIOS" to save it first. You make a wise choice to use Gigabyte, and @BIOS update your BIOS smartly. You are now worry free from updating wrong BIOS, and capable to maintain and manage your BIOS easily. Again, Gigabyte's innovative product erects a milestone in mainboard industries.

For such a wonderful software, how much it costs? Impossible! It's free! Now, if you buy a Gigabyte's motherboard, you could find this amazing software in the attached driver CD. But please remember, connected to internet at first, then you could have a internet BIOS update from your Gigabyte @BIOS.

EasyTune III™ Introduction

Gigabyte announces *EasyTune III* Windows overdrive utility



“Overdrive” might be one of the most common issues in computer field. But have many users ever tried it? The answer is probably “no”. Because “overdrive” is thought to be very difficult and includes a lot of technical know-how, sometimes “overdrive” is

even considered as special skills found only in some enthusiasts.

But as to the experts in “overdrive”, what’s the truth? They may spend quite a lot of time and money to study, try and use many different hardware and software tools to do “overdrive”. And even with these technologies, they still learn that it’s quite a risk because the safety and stability of an “overdrive” system is unknown.


Now everything is different because of a Windows overdrive utility EasyTuneIII --announced by Gigabyte. This utility has totally changed the gaming rule of “overdrive”. This is the first overdrive utility suitable for both normal and power users. Users can choose either “Easy Mode” or “Advanced Mode” to run “overdrive” at their convenience. For users who choose “Easy Mode”, they just need to click “Auto Optimize” to have auto and immediate CPU overclocking. This software will then overdrive CPU speed automatically with the result being shown in the control panel. If someone prefers to “overdrive” by oneself, there is also another choice. Click “Advanced Mode” to enjoy “sport drive” class overclocking. In “Advanced Mode”, one can change the system bus speed in small increments to get ultimate system performance. And no matter which mainboard is used, if it’s a Gigabyte’s product*, EasyTuneIII helps to perform the best of system.

Besides, different from other traditional over-clocking methods, EasyTuneIII doesn’t require users to change neither BIOS nor hardware switch/ jumper setting; on the other hand, they can do “overdrive” at only one click. Therefore, this is a safer way for “overdrive” as nothing is changed on software or hardware. If user runs EasyTuneIII over system’s limitation, the biggest lost is only to restart the computer again and the side effect is then well controlled. Moreover, if one well-performed system speed been tested in EasyTuneIII, user can “Save” this bus speed and “Load” it in next time. Obviously, Gigabyte EasyTuneIII has already turned the “overdrive” technology toward to a newer generation.

This wonderful software is now free bundled in Gigabyte motherboard attached driver CD. Users may make a test drive of "EasyTuneIII" to find out more amazing features by themselves.

For further technical information, please link to: <http://www.gigabyte.com.tw>

※ Note: If your TUCD version is 1.6 or below, please visit our website and download the latest EasyTune///™ version.

 Page Index for BIOS Setup	Page
The Main Menu	P.48
Standard CMOS Setup	P.50
BIOS Features Setup	P.53
Chipset Features Setup	P.55
Power Management Setup	P.58
PNP/ PCI Configuration	P.61
Load BIOS Defaults	P.62
Load Setup Defaults	P.63
Integrated Peripherals	P.64
Hardware Monitor Setup	P.68
Supervisor Password / User Password	P.69
IDE HDD Auto Detection	P.70
Save & Exit Setup	P.71
Exit Without Saving	P.72

BIOS Setup

BIOS Setup is an overview of the BIOS Setup Interface. The interface allows users to modify the basic system configuration, which is stored in battery-backed CMOS RAM so that it retains the Setup information can be retained when the power is turned off.

ENTERING SETUP

Power ON the computer and press immediately will allow you to enter Setup. If unsuccessful, you can restart the system and try again by pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl> – <Alt>– keys.

CONTROL KEYS

<↑>	Move to previous item
<↓>	Move to next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
<Esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F2>	Reserved
<F3>	Reserved
<F4>	Reserved
<F5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<F6>	Load the default CMOS value from BIOS default table, only for Option Page Setup Menu
<F7>	Load the Setup Defaults.
<F8>	Reserved
<F9>	Reserved
<F10>	Save all the CMOS changes, only for Main Menu

GETTING HELP

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

The Main Menu

Once you enter AMI BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. The Main Menu allows you to select from nine setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

AMIBIOS SIMPLE SETUP UTILITY-VERSION 1.23 (C) 1999 American Megatrends, Inc. All Rights Reserved	
STANDARD CMOS SETUP	INTEGRATED PERIPHERALS
BIOS FEATURES SETUP	HARDWARE MONITOR SETUP
CHIPSET FEATURES SETUP	SUPERVISOR PASSWORD
POWER MANAGEMENT SETUP	USER PASSWORD
PNP/PCI CONFIGURATION	IDE HDD AUTO DETECTION
LOAD BIOS DEFAULTS	SAVE & EXIT SETUP
LOAD SETUP DEFAULTS	EXIT WITHOUT SAVING
ESC : Quit ↑↓←→ : Select Item (Shift) F2 : Change Color F5 : Old Values F6 : Load BIOS Defaults F7: Load Setup Defaults F10: Save & Exit	
Time, Date, Hard Disk Type, ...	

Figure 1: Main Menu

- **Standard CMOS Setup**
This setup page includes all the adjustable items in standard compatible BIOS.
- **BIOS Features Setup**
This setup page includes all the adjustable items of Award special enhanced features.
- **Chipset Features Setup**
This setup page includes all the adjustable items of chipset special features.

- **Power Management Setup**

This setup page includes all the adjustable items of Green function features.

- **PnP/PCI Configurations**

This setup page includes all the adjustable configurations of PCI & PnP ISA resources.

- **Load BIOS Defaults**

Load BIOS Defaults option loads preset system parameter values to set the system in its most stable configurations.

- **Load Setup Defaults**

Load Setup Defaults option loads preset system parameter values to set the system in its highest performance configurations.

- **Integrated Peripherals**

This setup page includes all onboard peripherals.

- **Hardware Monitor Setup**

This setup page is auto detect fan and temperature status.

- **Set Supervisor Password**

Set Change or disable password. It allows you to limit access to the system and/or BIOS setup.

- **Set User Password**

Set Change or disable password. It allows you to limit access to the system.

- **IDE HDD auto detection**

Automatically configure hard disk parameters.

- **Save & Exit Setup**

Save CMOS value settings to CMOS and exit setup.

- **Exit Without Saving**

Abandon all CMOS value changes and exit setup.

Standard CMOS Setup

The items in Standard CMOS Features Menu (Figure 2) are divided into 9 categories. Each category includes none, one or more than one setup items. Use the arrows to highlight the item and then use the <PgUp> or <PgDn> keys to select the value in each item.

AMIBIOS SETUP – STANDARD CMOS SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved	
Date (mm/dd/yyyy) : Tue Jan 25, 2000 Time (hh/mm/ss) : 10:36:24	
TYPE	SIZE CYLS HEAD PRECOMP LANDZ SECTOR MODE
Pri Master : Auto	
Pri Slave : Auto	
Sec Master : Auto	
Sec Slave : Auto	
Floppy Drive A: 1.44 MB 3 ½	Base Memory : 640 Kb
Floppy Drive B: Not Installed	Other Memory: 384 Kb
	Extended Memory: 30Mb
Boot Sector Virus Protection : Disabled	Total Memory: 31Mb
Month: Jan – Dec	ESC : Exit
Day: 01 – 31	↑↓ : Select Item
Year: 1990– 2099	PU/PD/+/- : Modify
	(Shift)F2 : Color

Figure 2: Standard CMOS Setup

- **Date**

The date format is <Week>, <Month>, <Day>, <Year>.

Week	The week, from Sun to Sat, determined by the BIOS and is display-only
Month	The month, Jan. Through Dec.
Day	The day, from 1 to 31 (or the maximum allowed in the month)
Year	The year, from 1990 through 2099

- **Time**

The times format in <hour> <minute> <second>. The time is calculated base on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.

- **IDE Primary Master / Slave , Secondary Master / Slave**

The category identifies the type of hard disk from drive C to F that has been installed in the computer. There are two settings: Auto, and Manual. Manual: HDD type is user-definable; Auto will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation from your hard disk vendor or the system manufacturer.

CYLS.	Number of cylinders
HEADS	number of heads
PRECOMP	write precomp
LANDZONE	Landing zone
SECTORS	number of sectors

If a hard disk has not been installed select NONE and press <Enter>.

- **Drive A type / Drive B type**

The category identifies the type of floppy disk drive A or drive B that has been installed in the computer.

None	No floppy drive installed
360K, 5.25 in.	5.25 inch PC-type standard drive; 360K byte capacity.
1.2M, 5.25 in.	5.25 inch AT-type high-density drive; 1.2M byte capacity (3.5 inch when 3 Mode is Enabled).
720K, 3.5 in.	3.5 inch double-sided drive; 720K byte capacity
1.44M, 3.5 in.	3.5 inch double-sided drive; 1.44M byte capacity.
2.88M, 3.5 in.	3.5 inch double-sided drive; 2.88M byte capacity.

- **Boot Sector Virus Protection**

If it is set to enable, the category will flash on the screen when there is any attempt to write to the boot sector or partition table of the hard disk drive. The system will halt and the following error message will appear in the mean time. You can run anti-virus program to locate the problem.

Enabled	Activate automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table
Disabled	No warning message to appear when anything attempts to access the boot sector or hard disk partition table. (Default Value)

- **Memory**

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

Base Memory

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is typically 512 K for systems with 512 K memory installed on the motherboard, or 640 K for systems with 640 K or more memory installed on the motherboard.

Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1 MB in the CPU's memory address map.

Other Memory

This refers to the memory located in the 640 K to 1024 K address space. This is memory that can be used for different applications.

DOS uses this area to load device drivers to keep as much base memory free for application programs. Most use for this area is Shadow RAM

BIOS Features Setup

AMIBIOS SETUP – BIOS FEATURES SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved	
Processor Serial Number :Disabled First Boot Device :Floppy Second Boot Device :IDE-0 Third Boot Device :CDROM Floppy Drive Seek :Disabled Boot Up Num-Lock :On Password Check :Setup HDD S.M.A.R.T Capability :Disabled	ESC : Quit ↑↓←→: Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 :Color F6 : Load BIOS Defaults F7 : Load Setup Defaults

Figure 3: BIOS Features Setup

- Processor Serial Number**

Disabled	Disable CPU Serial Number. (Default Value)
Enabled	Enable CPU Serial Number.

- First / Second / Third Boot Device**

The default value is Floppy or LS/ ZIP A: or ATAPI ZIP C: or CDROM or SCSI or NETWORK or IDE-0-IDE-3 or Disabled.

Floppy	Set your boot device priority to Floppy.
LS/ ZIP A:	Set your boot device priority to LS/ ZIP A:.
CDROM	Set your boot device priority to CDROM.
SCSI	Set your boot device priority to SCSI.
NETWORK	Set your boot device priority to NETWORK.
IDE-0-IDE-3	Set your boot device priority to IDE-0-IDE-3.
Disabled	Disable this function.
ATAPI ZIP C:	Set your boot device priority to ATAPI ZIP C:.
USB FDD	Set your boot device priority to USB FDD.

● **Floppy Drive Seek**

During POST, BIOS will determine if the floppy disk drive installed is 40 or 80 tracks. 360 type is 40 tracks while 720 , 1.2 and 1.44 are all 80 tracks.

Enabled	BIOS searches for floppy disk drive to determine if it is 40 or 80 tracks. Note that BIOS can't differentiate between 720, 1.2 or 1.44 drive type as they are all 80 tracks.
Disabled	BIOS will not search for the type of floppy disk drive by track number. Note that there will not be any warning message if the drive installed is 360. (Default Value)

● **Boot Up Num-Lock**

On	Keypad is number keys. (Default Value)
Off	Keypad is arrow keys.

● **Password Check**

● Please refer to the detail on P.69

Setup	The user must enter correct password in order to access the system. (Default Value)
Always	The user must enter correct password in order to access the system and/or BIOS Setup.

● **HDD S.M.A.R.T. Capability**

Enabled	Enable S.M.A.R.T. Hard for Disks.
Disabled	Disable S.M.A.R.T. Hard for Disks. (Default Value)

Chipset Features Setup

⚠ We would not suggest you change the chipset default setting unless you really need it.

AMIBIOS SETUP –CHIPSET FEATURE SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved	
*** DRAM Timing ***	
DRAM Frequency	:100MHz
SDRAM CAS# Latency	:3
AGP Mode	:4X
AGP Fast Write	:Disabled
AGP Comp. Driving	:Auto
Manual AGP Comp. Driving	:CB
AGP Aperture Size	:64MB
DRAM Driver Strength	:Auto
MD Bus Strength	:High
CAS Bus Strength	:High
Delay DRAM Read Latch	:No Delay
Memory Data Driver	:6mA
SDRAM Command Driver	:16mA
Memory Address Driver	:16mA
CAS# Drive	:8mA
RAS# Drive	:16mA
ESC : Quit ↑↓←→: Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 :Color F6 : Load BIOS Defaults F7 : Load Setup Defaults	

Figure 4: Chipset Features Setup

- **DRAM Frequency**

100MHz	Set DRAM Frequency to 100MHz. (Default Value)
66MHz	Set DRAM Frequency to 66MHz.
133MHz	Set DRAM Frequency to 133MHz.

- **SDRAM CAS# Latency**

3	For Slower SDRAM DIMM module. (Default Value)
2	For Fastest SDRAM DIMM module.

- **AGP Mode**

4X	Set AGP Mode to 4X. (Default Value)
1X	Set AGP Mode to 1X.
2X	Set AGP Mode to 2X.

- **AGP Fast Write**

Disabled	Disable AGP Fast Write (Default Value)
Enabled	Enable AGP Fast Write

- **AGP Comp. Driving**

Auto	Detect AGP Comp. Driving automatically. (Default Value)
Manual	Set AGP Comp. Driving is Manual.

If AGP Comp. Driving is Manual.

Manual AGP Comp. Driving :	00-FF
----------------------------	-------

- **AGP Aperture Size**

4MB	Set AGP Aperture Size to 4MB.
8MB	Set AGP Aperture Size to 8 MB.
16MB	Set AGP Aperture Size to 16 MB.
32MB	Set AGP Aperture Size to 32 MB.
64MB	Set AGP Aperture Size to 64 MB. (Default Value)
128MB	Set AGP Aperture Size to 128 MB.
256MB	Set AGP Aperture Size to 256 MB.

- **DRAM Drive Strength**

● If DRAM Drive Strength is Manual, then you can adjust item below.

Auto	Detect DRAM Drive Strength automatically. (Default Value)
Manual	Set DRAM Drive Strength to Manual.

- **MD Bus Strength**

High	Set MD Bus Strength to High. (Default Value)
Low	Set MD Bus Strength to Low.

- **CAS Bus Strength**

High	Set CAS Bus Strength to High. (Default Value)
Low	Set CAS Bus Strength to High.

- **Delay DRAM Read Latch**

1.0ns	Set DRAM Read Latch Delay to 1.0ns.
1.5ns	Set DRAM Read Latch Delay to 1.5ns.
0.5ns	Set DRAM Read Latch Delay to 0.5ns.
No delay	Set DRAM Read Latch to No delay. (Default Value)

- **Memory Data Drive**

6 mA	Set Memory Data Drive to 6 mA. (Default Value)
8 mA	Set Memory Data Drive to 8 mA.

- **SDRAM Command Drive**

16 mA	Set SDRAM Command Drive to 16 mA. (Default Value)
24 mA	Set SDRAM Command Drive to 24 mA.

- **Memory Address Drive**

16 mA	Set Memory Address Drive to 16 mA. (Default Value)
24 mA	Set Memory Address Drive to 24 mA.

- **CAS# Drive**

8 mA	Set CAS# Drive to 8 mA. (Default Value)
12 mA	Set CAS# Drive to 12 mA.

- **RAS# Drive**

16 mA	Set RAS# Drive to 16 mA. (Default Value)
24 mA	Set RAS# Drive to 24 mA.

Power Management Setup

AMIBIOS SETUP –POWER MANAGEMENT SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved			
ACPI Sleep Type	:S1/POS	IRQ 11	:Ignore
USB Dev Wakeup From S3-S5	:Disabled	IRQ 13	:Ignore
Suspend Time Out(Minute)	:Disabled	IRQ 14	:Monitor
Soft-off by Power Button	:Instant off	IRQ 15	:Ignore
System after AC Back	:Off		
Modem Use IRQ	:4		
ModemRingOn/WakeOnLan	:Enabled		
PME Event Wake up	:Enabled		
Resume by RTC Alarm	:Disabled		
RTC Alarm Date	:Every Day		
RTC Alarm Hour	:12		
RTC Alarm Minute	:30		
RTC Alarm Second	:30		
Display Activity	:Ignore		
IRQ3	:Monitor		
IRQ 4	:Ignore	ESC : Quit	↑↓←→: Select Item
IRQ 5	:Monitor	F1 : Help	PU/PD/+/- : Modify
IRQ 7	:Ignore	F5 : Old Values (Shift)F2 :Color	
IRQ 9	:Monitor	F6 : Load BIOS Defaults	
IRQ 10	:Ignore	F7 : Load Setup Defaults	

Figure 5: Power Management Setup

- **ACPI Sleep Type**

S1/POS	Set ACPI sleep type to S1. (Default Value)
S3/STR	Set ACPI sleep type to S3.

- **USB Dev Wakeup From S3-S5**

Disabled	Disable USB device wakeup from ACPI S3,S4,S5 mode. (Default Value)
Enabled	Enable USB device wakeup from ACPI S3,S4,S5 mode.

- **Suspend Time Out (Minute)**

Disabled	Disable Suspend Time Out Function. (Default Value)
1	Set Suspend Time Out after 1min.
2	Set Suspend Time Out after 2min.
4	Set Suspend Time Out after 4min.
8	Set Suspend Time Out after 8min.
10	Set Suspend Time Out after 10min.
20	Set Suspend Time Out after 20min.
30	Set Suspend Time Out after 30min.
40	Set Suspend Time Out after 40min.
50	Set Suspend Time Out after 50min.
60	Set Suspend Time Out after 60min.

- **Soft-off by Power Button**

Instant off	The user press the power button once, he can turn off the system. (Default Value)
Suspend	The user press the power button once, then he can enter suspend mode.

- **System after AC Back**

Off	When AC-power back to the system, the system will be in "Off" state. (Default Value)
On	When AC-power back to the system, the system will be in "On" state.
Last State	When AC-power back to the system, the system will return to the Last state before AC-power off.

- **MODEM Use IRQ** (In APM mode, Support Modem wake up function from suspend)

N/A	Disabled this function.
3	Set MODEM use IRQ to 3.
4	Set MODEM use IRQ to 4. (Default Value)
5	Set MODEM use IRQ to 5.
7	Set MODEM use IRQ to 7.

- **ModemRingOn/WakeOnLan**

Disabled	Disable Modem Ring On / Wake On LAN function.
Enabled	Enable Modem Ring On / Wake On LAN function. (Default Value)

- **PME Event Wake up**

Disabled	Disable PME event wake up function.
Enabled	Enable PME event wake up function. (Default Value)

- **Resume by RTC Alarm**

You can set "Resume by RTC Alarm " item to enabled and key in Data/time to power on system.

Disabled	Disable this function. (Default Value)
Enabled	Enable alarm function to POWER ON system.

If Resume by RTC Alarm is Enabled.

RTC Alarm Date :	Every Day,1~31
RTC Alarm Hour:	0~23
RTC Alarm Minute :	0~59
RTC Alarm Second :	0~59

- **Display Activity** (In APM mode, Monitor display activity function from suspend)

Ignore	Ignore Display Activity. (Default Value)
Monitor	Monitor Display Activity.

- **IRQ(3,4,5,7,9,10,11,13,14,15)**

(In APM mode, Monitor IRQ3,4,5,7,9,10,11,13,14,15 event from suspend)

Ignore	Ignore IRQ3,4,5,7,9,10,11,13,14,15 event.
Monitor	Monitor IRQ3,4,5,7,9,10,11,13,14,15 event.

PnP/PCI Configurations

AMIBIOS SETUP -PnP/PCI CONFIGURATION SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved	
Reset Configuration Data :No	
VGA Boot From :PCI	
AGP Frame Buffer Size :8MB	
IRQ3 :PCI/PnP	
IRQ4 :PCI/PnP	
IRQ5 :PCI/PnP	
IRQ7 :PCI/PnP	
IRQ9 :PCI/PnP	
IRQ10 :PCI/PnP	
IRQ11 :PCI/PnP	
IRQ14 :PCI/PnP	
IRQ15 :PCI/PnP	
ESC : Quit ↑↓←→ : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 :Color F6 : Load BIOS Defaults F7 : Load Setup Defaults	

Figure 6: PnP/PCI Configuration

- **Reset Configuration Data**

To advise BIOS clear PnP configuration data for usable value.

Yes	Reset PnP configuration data in order to re-initialize ESCD for PnP device.
No	Disabled this function. (Default Value)

- **VGA Boot From**

AGP	Set VGA Boot from On Board AGP.
PCI	Set VGA Boot from Add-on PCI. (Default Value)

- **AGP Frame Buffer Size (on board AGP shared memory size)**

8MB	Set AGP Frame Buffer Size to 8MB. (Default Value)
16MB	Set AGP Frame Buffer Size to 16 MB.
32MB	Set AGP Frame Buffer Size to 32 MB.

- **IRQ (3,4,5,7,9, 10,11,14,15), assigned to ("ISA " or "PCI/PnP")**

ISA	The resource is used by Legacy ISA device.
PCI/PnP	The resource is used by PCI/ PnP device.

Load BIOS Defaults




Figure 7: Load BIOS Defaults

- **Load BIOS Defaults**

BIOS defaults contain the most appropriate system parameter values of to configure the system to achieve maximum stability.

Load Setup Defaults

AMIBIOS SIMPLE SETUP UTILITY-VERSION 1.23 (C) 1999 American Megatrends, Inc. All Rights Reserved	
STANDARD CMOS SETUP	INTEGRATED PERIPHERALS
BIOS FEATURES SETUP	HARDWARE MONITOR SETUP
CHIPSET FEATURES SETUP	SUPERVISOR PASSWORD
POWER MANAGE	Load SETUP Defaults (Y/N)? N
PNP/PCI CONFIGURATION	
LOAD BIOS DEFAULTS	SAVE & EXIT SETUP
LOAD SETUP DEFAULTS	EXIT WITHOUT SAVING
ESC : Quit ↑↓→← : Select Item (Shift) F2 : Change Color F5 : Old Values F6 : Load BIOS Defaults F7: Load Setup Defaults F10: Save & Exit	
Load Setup Default except Standard CMOS Setup	

Figure 8: Load Setup Defaults

- **Load Setup Defaults**

Load Setup defaults contain the most appropriate system parameter values to configure the system to achieve maximum performance.

Integrated Peripherals

AMIBIOS SETUP –INTEGRATED PERIPHERAL (C) 1999 American Megatrends, Inc. All Rights Reserved			
OnBoard IDE	:Both	MPU-401 I/O Address	:330h-333h
OnBoard FDC	:Enabled	Game Port(200h-207h)	:Enabled
OnBoard Serial Port 1	:Auto		
OnBoard Serial Port 2	:Auto		
Serial Port 2 Mode	:Normal		
Duplex Mode	:N/A		
OnBoard Parallel Port	:Auto		
Parallel Port Mode	:ECP		
Parallel Port DMA	:Auto		
Parallel Port IRQ	:Auto		
USB Controller	:All USB Port		
USB Legacy Support	:Disabled		
AC'97 Audio	:Auto		
AC'97 Modem	:Auto		
OnBoard Legacy Audio	:Enabled		
Sound Blaster	:Disabled	ESC : Quit	↑↓←→: Select Item
SB I/O Base Address	:220h-22Fh	F1 : Help	PU/PD/+/- : Modify
SB IRQ Select	:IRQ 5	F5 : Old Values (Shift)F2 :Color	
SB DMA Select	:DMA 1	F6 : Load BIOS Defaults	
MPU-401	:Disabled	F7 : Load Setup Defaults	

Figure 9: Integrated Peripherals

- **OnBoard IDE**

Disabled	Disable onboard IDE.
Both	Set onboard IDE to Both. (Default Value) .
Primary	Set onboard IDE to Primary.
Secondary	Set onboard IDE to Secondary.

- **OnBoard FDC**

Disabled	Disable onboard FDC..
Enabled	Enable onboard FDC. (Default Value)

- **OnBoard Serial Port 1**

Auto	BIOS will automatically setup the port 1 address. (Default Value) .
3F8/COM1	Enable onboard Serial port 1 and address is 3F8.
2F8/COM2	Enable onboard Serial port 1 and address is 2F8.
3E8/COM3	Enable onboard Serial port 1 and address is 3E8.
2E8/COM4	Enable onboard Serial port 1 and address is 2E8.
Disabled	Disable onboard Serial port 1.

- **OnBoard Serial Port 2**

Auto	BIOS will automatically setup the port 2 address. (Default Value)
3F8/COM1	Enable onboard Serial port 2 and address is 3F8.
2F8/COM2	Enable onboard Serial port 2 and address is 2F8.
3E8/COM3	Enable onboard Serial port 2 and address is 3E8.
2E8/COM4	Enable onboard Serial port 2 and address is 2E8.
Disabled	Disable onboard Serial port 2.

- **Serial Port 2 Mode**

ASKIR	Set onboard I/O chip IR mode to ASKIR .
Normal	Set onboard I/O chip IR mode to Normal. (Default Value)
IrDA	Set onboard I/O chip IR mode to IrDA.

- **Duplex Mode**

Half Duplex	IR Function Duplex Half.
Full Duplex	IR Function Duplex Full.
N/A	Disable this function. (Default Value)

- **On Board Parallel port**

378	Set on board LPT port and address is 378.
278	Set on board LPT port and address is 278.
3BC	Set on board LPT port and address is 3BC.
Auto	Set on board LPT port Automatically. (Default Value) .
Disabled	Disable this function.

- **Parallel Port Mode**

EPP	Using Parallel port as Enhanced Parallel Port.
ECP	Using Parallel port as Extended Capabilities Port. (Default Value)
Normal	Normal Operation.

- **Parallel Port DMA**

Auto	Set Parallel port DMA automatically. (Default Value)
3	Set Parallel Port DMA to 3.
1	Set Parallel Port DMA to 1.
0	Set Parallel Port DMA to 0.

- **Parallel Port IRQ**

7	Set Parallel Port IRQ to 7.
Auto	Set Parallel Port IRQ automatically. (Default Value) .
5	Set Parallel Port IRQ to 5.

- **USB Controller**

USB Port 0&1	USB Controller for USB Port 0&1.
USB Port 2&3	USB Controller for USB Port 2&3.
All USB Port	USB Controller for All USB Port. (Default Value)
Disabled	USB Controller Function Disabled.

- **USB Legacy Support**

Keyboard/FDD	Set USB Legacy Support Keyboard and Floppy Disk.
KB/Mouse/FDD	Set USB Legacy Support Keyboard ,Mouse and Floppy Disk.
Disabled	Disabled USB Legacy Support Function. (Default Value)

- **AC'97 Audio**

Auto	Set AC'97 Audio automatically. (Default Value) .
Disabled	Disable AC'97 Audio.

- **AC'97 Modem**

Auto	Set AC'97 Modem automatically. (Default Value) .
Disabled	Disable AC'97 Modem.

- **OnBoard Legacy Audio**

Enabled	Enable onboard Legacy Audio. (Default Value)
Disabled	Disable onboard Legacy Audio.

- **Sound Blaster**

Enabled	Enable Sound Blaster.
Disabled	Disable Sound Blaster. (Default Value)

- **SB I/O Base Address**

220h-22Fh	Set SB I/O Base Address to 220h-22Fh. (Default Value)
280h-28Fh	Set SB I/O Base Address to 280h-28Fh.
260h-26Fh	Set SB I/O Base Address to 260h-26Fh.
240h-24Fh	Set SB I/O Base Address to 240h-24Fh.

- **SB IRQ Select**

IRQ 5 / 7 / 9 / 10. (Default Value: 5)

- **SB DMA Select**

DMA 0 / 1 / 2 / 3. (Default Value: 1)
--

- **MPU-401**

Enabled	Enabled MPU-401.
Disabled	Disabled MPU-401. (Default Value)

- **MUP-401 I/O Address**

330h-333h	Set MUP-401 I/O Address to 330h-333h. (Default Value)
300h-303h	Set MUP-401 I/O Address to 300h-303h.
310h-313h	Set MUP-401 I/O Address to 310h-313h.
320h-323h	Set MUP-401 I/O Address to 320h-323h.

- **Game Port (200h-207h)**

Disabled	Disable Game Port (200h-207h).
Enabled	Enable Game Port (200h-207h). (Default Value)

Hardware Monitor

AMBIOS SETUP –HARDWARE MONITOR SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved	
- Hardware Monitor -	
Case Status	:Closed
Current CPU Temp.	:36°C/96°F
Current System Temp.	:28°C/82°F
Current CPU Fan Speed	:5487 RPM
Current System Fan Speed	:0 RPM
Vcore	:2.075V
+3.300V	:3.590V
+5.000V	:5.119V
+12.000V	:11.926V
ESC : Quit ↑↓←→ : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 : Color F6 : Load BIOS Defaults F7 : Load Setup Defaults	

Figure 10: Hardware Monitor

- **Case Status**

If the case is closed, "Case Status" will show "Closed".
If the case is opened, "Case Opened" will show "Opened".

- **Current CPU Temp. (°C / °F)**

Detect CPU Temperature automatically.

- **Current System Temp. (°C / °F)**

Detect System Temperature automatically.

- **Current CPU FAN Speed**

Detect CPU Fan speed status automatically .

- **Current System FAN Speed**

Detect System Fan speed status automatically .

- **Current Voltage (V) Vcore / +3.3V / +5V / +12V**

Detect system's voltage status automatically.

Set Supervisor / User Password

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.




Figure 11: Password Setting

Type the password, up to six characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message **"PASSWORD DISABLED"** will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

The BIOS Setup program allows you to specify two separate passwords: a **SUPERVISOR PASSWORD** and a **USER PASSWORD**. When disabled, anyone may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration fields, the User password is required to access only basic items.

If you select **"Always"** at **"Password Check"** in BIOS Features Setup Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.

If you select **"Setup"** at **"Password Check"** in BIOS Features Setup Menu, you will be prompted only when you try to enter Setup.

IDE HDD AUTO Detection

AMIBIOS SETUP – STANDARD CMOS SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved							
Date (mm/dd/yyyy) : Tue Jan 25, 2000							
Time (hh/mm/ss) : 10:36:24							
TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
Pri Master : Not Installed							
Pri Slave : Not Installed							
Sec Master : Not Installed							
Sec Slave : Not Installed							
Floppy Drive A: 1.44 MB 3 ½				Base Memory : 640 Kb Other Memory: 384 Kb Extended Memory: 31Mb Total Memory: 32Mb			
Floppy Drive B: Not Installed							
Boot Sector Virus Protection : Disabled							
Month: Jan – Dec				ESC : Exit			
Day: 01 – 31				↑↓ : Select Item			
Year: 1990– 2099				PU/PD/+/- : Modify (Shift)F2 : Color			

Figure 12: IDE HDD Auto Detection

Type "Y" will accept the H.D.D. parameter reported by BIOS.

Type "N" will keep the old H.D.D. parameter setup. If the hard disk cylinder number is over 1024, then the user can select LBA mode or LARGER mode for DOS partition larger than 528 MB.

Save & Exit Setup




Figure 13: Save & Exit Setup

Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.

Type "N" will return to Setup Utility.

Exit Without Saving

AMIBIOS SIMPLE SETUP UTILITY-VERSION 1.23 (C) 1999 American Megatrends, Inc. All Rights Reserved	
STANDARD CMOS SETUP	INTEGRATED PERIPHERALS
BIOS FEATURES SETUP	HARDWARE MONITOR SETUP
CHIPSET FEATURES SETUP	SUPERVISOR PASSWORD
POWER MANAGEMENT SETUP	USER PASSWORD
PNP/PCI CONFIGURATION	IDE HDD AUTO DETECTION
LOAD BIOS DEFAULTS	Quit without saving (Y/N) ? N
LOAD SETUP DEFAULTS	
ESC : Quit ↑↓←→ : Select Item (Shift) F2 : Change Color F5 : Old Values F6 : Load BIOS Defaults F7 : Load Setup Defaults F10 : Save & Exit	
Abandon all Datas & Exit Setup	

Figure 14: Exit Without Saving

Type "Y" will quit the Setup Utility without saving to RTC CMOS.

Type "N" will return to Setup Utility.



Technical Support /RMA Sheet

Customer/Country:	Company:	Phone No.:
Contact Person:	E-mail Add. :	

Model name/Lot Number:	PCB revision:
BIOS version:	O.S./A.S.:

Hardware Configuration	Mfs.	Model name	Size:	Driver/Utility:
CPU				
Memory Brand				
Video Card				
Audio Card				
HDD				
CD-ROM / DVD-ROM				
Modem				
Network				
AMR / CNR				
Keyboard				
Mouse				
Power supply				
Other Device				

Problem Description:




Appendix


Appendix A : VIA Chipsets Driver Installation

A.VIA 4 in 1 Service Pack Utility:


Insert the support CD that came with your motherboard into your CD-ROM driver or double –click the CD driver icon in My Computer to bring up the screen.




(1)




(2)




(3)




(4)




(5)




(6)



(7)




(8)



(9)




(10)




B.AC'97 Audio Driver:


Insert the support CD that came with your motherboard into your CD-ROM driver or double-click the CD driver icon in My Computer to bring up the screen.




(1)



(2)




(3)




(4)

C. LAN Driver: (Optional)


Insert the support CD that came with your motherboard into your CD-ROM driver or double-click the CD driver icon in My Computer to bring up the screen.




(1)




(2)



(3)



(4)




(5)

5. Click "Yes" to Finish.


D. VGA Driver:

Insert the support CD that came with your motherboard into your CD-ROM driver or double-click the CD driver icon in My Computer to bring up the screen.




1. Click "Advanced" item.

(1)




2. Click "Change" item.

(2)




3. Click "Next"

(3)




4. Click "Next".

(4)




5. You can select "Specify a location:
D:\Chipset\Via\Vt8605\Win9x
then Click "Next"

(5)



6. Click "Next".

(6)




(7)

Appendix B: BIOS Flash Procedure

BIOS update procedure:

If your OS is Win9X, we recommend that you used Gigabyte @BIOS Program to flash BIOS.



Methods and steps :

I. Update BIOS through Internet

- a. Click "Internet Update" icon
- b. Click "Update New BIOS" icon
- c. Select @BIOS sever ("Gigabyte @BIOS sever 1 in Taiwan" and "Gigabyte @BIOS sever 2 in Taiwan" are available for now, the others will be completed soon)
- d. Select the exact model name on your motherboard
- e. System will automatically download and update the BIOS.

II. Update BIOS **NOT** through Internet :

- a. **Do not** click "Internet Update" icon
- b. Click "Update New BIOS"
- c. Please select "All Files" in dialog box while opening the old file.
- d. Please search for BIOS unzip file, downloading from internet or any other methods (such as: 6PMM.F1).
- e. Complete update process following the instruction.

III. Save BIOS

In the very beginning, there is "Save Current BIOS" icon shown in dialog box. It means to save the current BIOS version.

IV. Check out supported motherboard and Flash ROM :

In the very beginning, there is "About this program" icon shown in dialog box. It can help you check out which kind of motherboard and which brand of Flash ROM are supported.

Note :

- a. In method I, if it shows two or more motherboard's model names to be selected, please make sure your motherboard's model name again. Selecting name will cause the system unbooted.
- b. In method II, be sure that motherboard's model name in BIOS unzip file are the same as your motherboard's. Otherwise, your system won't boot.
- c. In method I, if the BIOS file you need cannot be found in @BIOS server, please go onto Gigabyte's web site for downloading and updating it according to method II.
- d. Please note that any intercorruption during updating will cause system unbooted

Or else you can select flash BIOS in DOS mode.

● Please check your **BIOS vendor (AMI or AWARD)**, your **motherboard name** and **PCB version** on the motherboard.

1. Format a bootable system floppy diskette by the command "**format a:/s**" in command mode.
2. Visit the Gigabyte website at [http:// www.gigabyte.com.tw](http://www.gigabyte.com.tw) ,Select the BIOS file you need and download it to your bootable floppy diskette.
3. Insert the bootable diskette containing the BIOS file into the floppy diskette driver.
4. Assuming that the floppy diskette driver is A, reboot the system by using the A: driver. At the A: > prompt, run the BIOS upgraded file by executing the Flash BIOS utility and the BIOS file with its appropriate extension.

Example: *(AMI tool) (Where 6PMM.f1 is name of the BIOS file name)*

A:>flashxxx.exe 6PMM.f1 ↵

Example: *(Award tool) (Where 6PMM.f1 is name of the BIOS file name)*

A:>wdfash.exe 6PMM.f1 ↵

5. Upon pressing the <Enter> key, a flash memory writer menu will appear on screen. Enter the new BIOS file name with its extension filename into the text box after file name to program.
6. If you want to save the old BIOS file(perform as soon as system is operational, this is recommended), select Y to **DO YOU WANT TO SAVE BIOS**, then type the old BIOS filename and the extension after filename to save: This option allows you to copy the contents of the flash memory chip onto a diskette, giving you a backup copy of the original motherboard BIOS in case you need to re-install it. Select N to **DO YOU WANT TO SAVE BIOS**, if you don't want to save the old BIOS file.
7. After the decision to save the old BIOS file or not is made, select Y to **ARE YOU SURE TO PROGRAM** when the next menu appear; wait until a message showing Power Off or Reset the system appears. Then turn off your system.
8. Remove the diskette and restart your system.
9. Hold down <Delete> key to enter BIOS setup. You must select "Load Setup BIOS Default" to activate the new BIOS, then you may set other item from the main menu.

Appendix C: Issues To Beware Of When Installing AMR

Please use inverse AMR card like the one in order to avoid mechanical problem. (See Figure A)




Figure A: Inverse AMR Card (Default)




Figure B: Non inverse AMR Card

Appendix D: Acronyms

Acronyms	Meaning
ACPI	Advanced Configuration and Power Interface
APM	Advanced Power Management
AGP	Accelerated Graphics Port
AMR	Audio Modem Riser
ACR	Advanced Communication Riser
BIOS	Basic Input / Output System
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRM	Dual Retention Mechanism
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCD	Extended System Configuration Data
ECC	Error Checking and Correcting
EMC	Electromagnetic Compatibility
EPP	Enhanced Parallel Port
ESD	Electrostatic Discharge
FDD	Floppy Disk Device
FSB	Front Side Bus
HDD	Hard Disk Device
IDE	Integrated Dual Channel Enhanced
IRO	Interrupt Request
I/O	Input / Output
IOAPIC	Input Output Advanced Programmable Input Controller
ISA	Industry Standard Architecture
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Interface Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System

To be continued...

6PMM Series Motherboard

Acronyms	Meaning
OEM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory
SMP	Symmetric Multi-Processing
SMI	System Management Interrupt
USB	Universal Serial Bus
VID	Voltage ID