



T h e S o u l O f C o m p u t e r T e c h n o l o g y

SL-75LIV

USER MANUAL v1.0

NOTICE

Product Model	: SL-75LIV
Manual Revision	: V1.0
Release Date	: July 2001

This Users Guide & Technical Reference is to help system manufacturers and end-users set up and install the mainboard. Every effort has been made to ensure that the information in this manual is accurate. Soltek Computer Inc. is not responsible for printing or clerical errors. Information in this document is subject to change without notice and does not represent a commitment on the part of Soltek Computer Inc.

No part of this manual may be reproduced, transmitted, translated into any language in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of Soltek Computer Inc.

Companies and products mentioned in this manual are for identification purpose only. Product names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies.

Soltek Computer Inc. provides this manual “As is “ without warranty of any kind, either express or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose. In no event shall Soltek Computer Inc. be liable for any loss or profits, loss of business, loss of use or data, interruption of business, or for indirect, special, incidental, or consequential damages of any kind, even if Soltek Computer Inc. has been advised of the possibility of such damages arising from any defect or error in this manual or product.

Copyright © 2001 Soltek Computer Inc. All Rights Reserved.

- AMD Athlon Thunderbird™, and Duron™ processors are trademarks of AMD Corporation.
- VIA, VT8601A APOLLO PLE133 and VT82C686B are trademarks of VIA Corporation.

SOLTEK AROUND THE WORLD

SOLTEK COMPUTER INC.

Address : 7F, No. 306-3, Ta-Tung Rd, Sec.1, Hsi-Chih, Taipei-Hsien, Taiwan, R.O.C.
Telephone : 886-2-2642-9060
Fax : 886-2-2642-9065
E-mail : sales@soltek.com.tw
Web site : <http://www.soltek.com.tw>

SOUL TECHNOLOGY EUROPE B.V.

Address : Hongkongstraat 55, 3047 BP Rotterdam. The Netherlands
Telephone : 31-10-2457492
Fax : 31-10-2457493
E-mail : sales@soultech-europe.com
Web site : <http://www.soultech-europe.com>

CONTENTS

CHAPTER 1 INTRODUCTION	8
1-1 MAINBOARD SPECIFICATION	9
1-1.1 PROCESSOR	9
1-1.2 CHIPSET	9
1-1.3 ADVANCED HIGH-PERFORMANCE DRAM CONTROLLER	9
1-1.4 INTEGRATED HIGH PERFORMANCE 2D/3D GRAPHICS .	9
CONTROLLER	9
1-1.5 AWARD BIOS V6.0	9
1-1.6 SOUND CONTROLLER	10
1-1.7 MULTI-I/O FUNCTION	10
1-1.8 POWER MANAGEMENT	10
1-1.9 HARDWARE MONITOR	10
1-1.10 EXPANSION SLOTS	11
1-1.11 FORM FACTOR	11
1-1.12 OTHERS	11
1-2 MOTHERBOARD LAYOUT --- 75LIV	12
1-3 CHIPSET DIAGRAM--- 75LIV	13
 CHAPTER 2 HARDWARE SETUP	 15
2-1 CPU INSTALLATION	16
2-2 MEMORY INSTALLATION	17
2-3 HDD/FDD INSTALLATION	18
2-4 SWITCH SETTING FOR CPU FREQUENCY AND VOLTAGE.	20
2-4.1 Information On AMD Socket 462 Processor	20
2-4.2 CPU External Frequency Setting (By SW1)	21
2-4.3 Processor Core Voltage Select (By SW2 DIP1-DIP6)	22
2-4.4 Frequency Ratio Select (By SW3 DIP1-DIP4)	23
2-5 JUMPER SETTING FOR DEVICES ON BOARD	24
2-5.1 JBAT1 For Clear CMOS Data	24

2-6 CONNECTORS CONFIGURATIONS	25
2-6.1 On Board FAN Connector (FAN1, FAN2, FAN3)	25
2-6.2 WOL1 Wake On LAN	26
2-6.3 CD-ROM Audio Connector (CD_IN1/CD_IN2)	26
2-6.4 Complex Header NJP1	27
2-6.5 Chassis Panel Connector	28
2-6.6 ATX Power Supply Connector	29
2-6.7 PS/2 Mouse And PS/2 Keyboard	29
2-6.8 Serial Ports	30
2-6.9 USB2 Header	31
2-7 IRQ DESCRIPTION	32
CHAPTER 3 SOFTWARE SETUP	34
3-1 VIA CHIPSET DRIVER INSTALLATION (4-IN-1 DRIVER)	35
3-2 ONBOARD VGA DRIVER INSTALLATION	38
3-2.1 Install KLE133 VGA Driver For Windows 95/98/SE	38
3-2.2 Install KLE133 VGA Driver For Windows NT4.0	38
3-2.3 Install KLE133 VGA Driver For Windows ME	39
3-2.4 Install KLE133 VGA Driver Windows 2000	39
3-3 AC'97 AUDIO CODEC INSTALLATION	40
CHAPTER 4 BIOS SETUP	42
4-1 WHAT IS BIOS SETUP	43
4-2 HOW TO RUN BIOS SETUP	43
4-3 WHAT IS CMOS	43
4-4 WHAT IS POST	43
4-5 BIOS UPGRADE	43
4-5.1 Before Upgrading BIOS	44
4-5.2 Upgrade Process	44

4-6 BIOS SETUP --- CMOS SETUP UTILITY 48

 4-6.1 CMOS SETUP UTILITY 48

 4-6.2 STANDARD CMOS SETUP 49

 4-6.3 ADVANCED BIOS FEATURES 52

 4-6.4 ADVANCED CHIPSET FEATURES 57

 4-6.5 INTEGRATED PERIPHERALS 63

 4-6.6 POWER MANAGEMENT SETUP 68

 4-6.7 PNP / PCI CONFIGURATION 75

 4-6.8 SMARTDOC ANTI-BURN SHIELD 78

 4-6.9 FREQUENCY/VOLTAGE CONTROL 80

 4-6.10 LOAD OPTIMIZED DEFAULTS 82

 4-6.11 SET SUPERVISOR / USER PASSWORD 83

 4-6.12 SAVE & EXIT SETUP 84

 4-6.13 EXIT WITHOUT SAVING 84

APPENDICES 86

 APPENDIX-1 TECHNICAL TERMS 87

 APPENDIX-2 IDENTIFYING BIOS VERSION AND BIOS PART
 NUMBER 88

 APPENDIX-3 IDENTIFYING MAINBOARD MODEL NUMBER 90

ITEMLIST CHECKUP

- Mainboard
- Support CD
- User's Manual
- Bundled Bonus Pack CD
- Bundled Bonus Pack Manual
- ATA66/100 IDE Cable
- RS232 Cable
- FDD Cable

CHAPTER 1

INTRODUCTION

- This chapter briefly introduces the characteristics of this mainboard. It includes the information regarding the chipset, CPU types, built-in functions and layout. Users will have more ideas about mainboards after reading this chapter.

This chapter contains the following topics :

- 1-1 MAINBOARD SPECIFICATION**
- 1-2 MAINBOARD LAYOUT**
- 1-3 CHIPSET DIAGRAM**

1-1 MAINBOARD SPECIFICATION

1-1.1 PROCESSOR

- Supporting AMD Athlon™ Thunderbird processors up to 1.5GHz.
- Supporting AMD Athlon™ Duron processors up to 1.2GHz.
- Supporting processor VID (voltage ID) and FID (frequency ID) auto detection.
- Supporting AMD Athlon™ processor with 200 and 266MHz Front Side bus.
- Supporting AMD Athlon™ 4 processors (Palomino).

1-1.2 CHIPSET

- North Bridge VIA VT8361 (KLE-133) system controller High Performance Athlon CPU Interface.
- South Bridge VIA VT82C686B PCI to ISA bridge.

1-1.3 ADVANCED HIGH-PERFORMANCE DRAM CONTROLLER

- Supporting PC133 and PC100 SDRAM up to 3 DIMMs.
- 64-bit data width and 3.3V DRAM interface.
- Supporting up to 768MB memory space.
- Supporting different DRAM types may be used in mixed combinations.

1-1.4 INTEGRATED HIGH PERFORMANCE 2D/3D GRAPHICS CONTROLLER

- 64-bit Single Cycle 2D/3D Graphics Engine.
- Supporting 8 Mbytes of Frame Buffer.
- Integrated 24 bit 230MHz True Color DAC.
- Extended Screen Resolutions up to 1600x1200.
- Extended Text Mode 80 or 132 columns by 25/30/43/60 rows.
- Supporting full AGP v2.0 capability.

1-1.5 AWARD BIOS V6.0

- Plug & Play V1.0.
- Flash Memory for easy upgrade.
- BIOS writing protection.
- Year 2000 compliant.
- SMARTDOC ANTI-BURN SHIELD.
- RedStorm Overclocking Tech.

1-1.6 SOUND CONTROLLER

- SoundBlaster Pro Hardware and Direct Sound Ready AC97 Digital Audio Controller with Codec onboard.

1-1.7 MULTI-I/O FUNCTION

- Two Ultra DMA 33/66/100 Master Mode PCI EIDE ports.
- Two UART's for Complete Serial Ports.
- Dedicated IR connector:
 - Third serial port dedicated to IR function either through the two complete serial ports or the third dedicated port Infrared-IrDA (HPSIR) and ASK (Amplitude Shift Keyed) IR.
- Multi-mode parallel connector supporting:
 - Standard mode, ECP and EPP.
- Floppy Disk connector supporting:
 - Two FDDs connector with drive swap support .
- Universal Serial Bus connector supporting:
 - USB v1.1 and Intel Universal HCI v1.1 compatible.
 - 2 built-in USB connectors and one USB Header (USB2) which requires an optional USB cable to provide 2 more optional USB ports.
- PS/2 Keyboard connector.
- PS/2 Mouse connector.

1-1.8 POWER MANAGEMENT

- ACPI 1.0 compliant (Advanced Configuration and Power Interface).
- APM V1.2 compliant (Legacy power management).
- Supporting ACPI POS mode (Power On Suspend).
- Supporting Wake On LAN (WOL) & Wake On Modem (WOM).
- Supporting real time clock (RTC) with date alarm, month alarm, and century field.

1-1.9 HARDWARE MONITOR

- Programmable control, status, to provide monitoring and alarm for flexible desktop management of hardware temperature (software provided in support CD).
- 5-positive voltage.
- 2 Fan-speeds statuses monitoring.

1-1.10 EXPANSION SLOTS

- Three PCI bus Master slots.
- One ISA slot.
- Three DIMM slots.

1-1.11 FORM FACTOR


- ATX form factor 4-layer PCB.
- Mainboard size: 24.5cm x 21.0cm.

1-1.12 OTHERS

- Clock generator supporting 1 MHz linear clock setting.

1-2 MOTHERBOARD LAYOUT --- 75LIV

- Default Setting: 100MHz CPU External clock.



Using non-compliant memory with higher bus clock (over-clocking) may severely compromise the reliability of system.

1-3 CHIPSET DIAGRAM--- 75LIV

- The KLE-133 / VT82C686B chipset is a high performance, cost-effective and energy efficient system controller for the implementation of AGP / PCI / ISA desktop personal computer system based on 64-bit Socket-A (AMD Athlon) processors.




Diagram of KLE133 System Block with VT82C686B South Bridge

MEMO

CHAPTER 2

HARDWARE SETUP

ATTENTION !!!

1. Please refer to your processor installation or other documentation attached to your CPU for more detailed installing instruction.
2. Installing a heat sink and cooling fan is necessary for proper heat dissipation from your CPU. Incorrect installation may result in overheating and damage of your CPU.
3. Before changing the setting of CPU Vcore from BIOS program, user SHOULD make sure of correct specification both of CPU CLOCK and RATIO. Incorrect setting may cause damage to your CPU.


This chapter contains the following topics :

- 2-1 CPU INSTALLATION
- 2-2 MEMORY INSTALLATION
- 2-3 HDD/FDD INSTALLATION
- 2-4 SWITCH SETTING FOR CPU FREQUENCY AND VOLTAGE
- 2-5 JUMPER SETTING FOR DEVICES ON BOARD
- 2-6 CONNECTORS CONFIGURATION
- 2-7 IRQ DESCRIPTION


2-1 CPU INSTALLATION

WARNING !!!


- Make sure that +5V DCV and +3.3 DCV capabilities of your power supply are suitable for the processor.
- Any attempt to operate the AMD Athlon or Duron processor without a suitable cooling Fan will damage processor and other component.



1 Pull out the lever from the socket, and then raise the lever up to a 90-degree angle.



2 Take notice of the red circles as shown here. While inserting the CPU into the socket, you can find out there is a definite pin orientation for CPU and socket.



3 Make sure that the CPU is placed into the socket tightly. Then lower down the lever to complete the CPU installation.


2-2 MEMORY INSTALLATION

WARNING!!!

- *Make sure to unplug your power supply before adding or removing memory modules or other system components. Failure to do so may cause severe damage to both your mainboard and expansion cards.*
- *Be careful when inserting or removing DIMM. Forcing a DIMM in or out of a socket improperly may damage the memory module or the socket. Some DIMMs which contain EDO or FPM DRAM are incompatible with the mainboard. The M/B supports 3.3V true SDRAM DIMMs only.*

Installing DIMM

- Make sure you have the correct memory module type for your mainboard.
- Insert the module(s) as shown below, DIMMs have 168-pins and two notches that will be matched by the onboard DIMM socket. Memory modules are installed by inserting them straight into the slot until they “click” in the right place. They only fit in one direction, so do not force them in by a wrong direction.




Removing DIMM


- Press down the holding clips on both sides of a DIMM socket and the module will be released from it.

2-3 HDD/FDD INSTALLATION

- To install HDD (Hard Disk Drive), you may connect the cable's blue connector to the mainboard's primary (IDE1) or secondary (IDE2) connector, and then connect the gray connector to your slave device and the black connector to your master device. If you install two hard disks, you must configure the second drive to Slave mode by setting its jumper accordingly. Please refer to your hard disk documentation for the jumper settings.




Hard Disk Drive Connector:
Orient the red line on the
IDE ribbon cable to Pin 1.




IDE Cable

- To install FDD (Floppy Disk Drive), you may connect the end with single connector to the board , and connect the other end with two plugs to the floppy drives.



Floppy Disk Drive Connector:
Orient the red line on the floppy ribbon cable to Pin1.




FDD Cable












2-4 SWITCH SETTING FOR CPU FREQUENCY AND VOLTAGE

2-4.1 Information On AMD Socket 462 Processor

- On the AMD Socket 462 Processor, you can find a codified identification marking which is to provide useful information about the CPU. The marking is interpreted as below:



2-4.2 CPU External Frequency Setting (By SW1)

SW1	CPU EXTERNAL FREQUENCY	PCI FREQUENCY	FSB FREQUENCY
	100MHz (Default)	33.3MHz	200MHz
	103MHz	34.3MHz	206MHz
	105MHz	35.0MHz	210MHz
	110MHz	36.7MHz	220MHz
	112MHz	37.3MHz	224MHz
	115MHz	38.3MHz	230MHz
	120MHz	40.0MHz	240MHz
	124MHz	31.0MHz	248MHz
	133.3MHz	33.3MHz	266MHz
	140MHz	35.0MHz	280MHz
	150MHz	37.5MHz	300MHz

IMPORTANT:

- You may figure out the correct processor type by processor's OPN (Ordering Part Numbers). Correct CPU external frequency is key to ensure reliability of your system.
- Incorrect CPU external frequency or overclocking might cause unstable performance, so we strongly recommend to leave "SW1" at default setting or legal operation.

2-4.3 Processor Core Voltage Select (By SW2 DIP1-DIP6)


- DIP1-DIP6 SW2 allow you to adjust processor core voltage manually.
- We recommend to leave SW2 DIP1 at default**, the default means the correct processor core voltage is generated according to VID of CPU.

SW2 DIP2 ~ DIP6 SETTING			SW2 DIP1
0.0v (Default)		1.100v	Auto (Default) By DIP 2-6
1.150v		1.175v	
1.225v		1.250v	
1.300v		1.325v	
1.375v		1.400v	
1.450v		1.475v	
1.525v		1.550v	
1.600v		1.625v	
1.675v		1.700v	
1.750v		1.775v	
1.825v		1.850v	SW2 DIP 1 allows you to enable or disable "Processor Core Voltage Select" function.

2-4.4 Frequency Ratio Select (By SW3 DIP1-DIP4)

- The AMD Athlon and Duron processors provides four Frequency ID signals (DIP1-DIP4) (FID) for the system controller to indicate the SYSTCLK multiplier at which the processor core operates. Normally, multiplier (or bus ratio) is detected automatically. Therefore, if the processor does not support the function, then “Bus Ratio” can not be selected.
- When DIP5 of SW3 is on, LED “LED1” will be on, and light is on, it means that Bus Ratio Select Function is enabled. So as long as your CPU supports Bus Ratio Select function, then Bus Ratio can be selected by users.

NOTICE : Setting of multiplier 12.5x or above will depend on the type of CPU on board .



SW3 DIP1 ~ DIP4 SETTING				SW3 DIP5
5.5x		6.0x (Default)		Bus ratio detected by FID (Auto)
6.5x		7.0x		
7.5x		8.0x		Bus ratio selected by SW1 DIP 1-4
8.5x		9.0x		
9.5x		10.0x		SW1 DIP 5 allows you to enable or disable the "Frequency Ratio Select" function.
10.5x		11.0x		
11.5x		12.0x		
* 12.5x or 13.0x		14.0x		

* Setting of Multiplier 12.5x or above will depend on the type of CPU on board.

2-5 JUMPER SETTING FOR DEVICES ON BOARD


- The following diagrams show the locations of jumper blocks on the mainboard.

CAUTION





- *Do not remove the jumper when power is on. Always make sure the power is off before changing any jumpers. Otherwise, mainboard could be damaged..*
- *All jumper pins covered with black marks are closed pins.*

2-5.1 JBAT1 For Clear CMOS Data

A battery should be used to supply the power for the CMOS RAM to retain the mainboard configuration.



JBAT1 For Clear CMOS Data:


Clear CMOS Data	  JBAT1
Retain Data (default)	  JBAT1

NOTE: *You can clear CMOS by 2-3 pin closed when the system is POWER OFF. Then, return to 1-2 pin closed position (default). You may damage the mainboard if clearing the CMOS with POWER ON. Unplugging the power cord from power supply before clearing CMOS will be a safest bet for user.*

2-6 CONNECTORS CONFIGURATIONS

- This section lists out all connectors configurations for users' reference.




2-6.1 On Board FAN Connector (FAN1, FAN2, FAN3)



On Board FAN Connector (FAN1):

On Board FAN Connector (FAN2):

On Board FAN Connector (FAN3):

CPU FAN		FAN1
SYSTEM FAN		FAN2
CHASSIS FAN		FAN3




These fan connectors support CPU/System chassis cooling fan with +12V. When connecting wire to FAN connectors, users should pay attention that the red wire is for the positive current and should be connected to pin +12V, and the black wire is Ground and should be connected to pin GND. If your mainboard has Hardware Monitor chipset on-board, you must use a specially designed fan with speed sensor to take advantage of this function.

For fans with speed sensors, each rotation of the fan blades will send out 2 electric pulses, by which System Hardware Monitor will work out the fan rotation speed by counting the pulses.

NOTE 1: Always consult vendor for proper CPU cooling fan.

NOTE 2: CPU FAN is supported by Hardware Monitor, with which a warning will be given out against high CPU temperature.


2-6.2 WOL1 Wake On LAN



This connector is connected to the LAN card with a Wake On LAN output. The connector powers up the system when it receives a wake-up packet or signal through the LAN card.


This feature requires that Wake On LAN feature is enabled in the **“Power Management Setup”** of BIOS setting and that your system must be on an ATX power supply with at least 720mA / +5V standby power.

2-6.3 CD-ROM Audio Connector (CD_IN1/CD_IN2)



2-6.4 Complex Header NJP1

- This complex Header consists of 8 connectors providing various supports:



1. Power Switch Connector:

CONNECTION: Connected to a momentary button or switch.

FUNCTION: Manually switching the system between “On” and “Soft Off”. Pressing the momentary button for more than 4 seconds will also turn the system off.

2. IR Connector (Infrared Connector):

CONNECTION: Connected to Connector IR on board.

FUNCTION: Supporting wireless transmitting and receiving module on board.

3. 1st HDD LED Connector / J2 2nd HDD LED Connector:

CONNECTION: Connected to HDD LED.

FUNCTION: To supply power to HDD LED.

4. Suspend LED Connector:

CONNECTION: Connected to Suspend indicator.

FUNCTION: To supply power to “Suspend indicator”.

5. Power LED Connector:

CONNECTION: Connected to System Power LED.

FUNCTION: To supply power to “System Power LED”.

6. Reset Switch Connector:

CONNECTION: Connected to the case-mounted “Reset Switch”.


FUNCTION: To supply power to “Reset Switch” and support system reboot function.

7. Speaker Connector:

CONNECTION: Connected to the case-mounted Speaker.

FUNCTION: To supply power to the case-mounted Speaker.


2-6.5 Chassis Panel Connector




- A : PS/2 MOUSE PORT
- B : USB 0 PORT
- C : LPT1 PORT
- D : GAME/MIDI PORT
- E : PS/2 KEYBOARD PORT
- F : USB 1 PORT
- G : COM 1 PORT
- H : VGA PORT
- I : LINE OUT / SPEAKER OUT PORT
- J : LINE IN
- K : MICROPHONE

2-6.6 ATX Power Supply Connector

- This connector connects to an ATX power supply. The plug from the power supply should only be inserted to ATX Power connector in a specific orientation. Find the proper orientation and push it down firmly to make sure that all pins are aligned.
- Your power supply should support at least 10mA on the 5V standby voltage. It may cause difficulty to turn on the system power if the power supply does not support the load.
- **For Wake On LAN function, the power supply should support at least 720mA current.**




2-6.7 PS/2 Mouse And PS/2 Keyboard




2-6.8 Serial Ports

- One serial port COM 1 is ready for a mouse or other serial devices. A second serial port is available in the form of a 9-pin Header (COM2) to provide connection to a second serial device by an RS232 cable.




COM 2 Header



PIN1


COM 2 Header:
Orient the red markings on the floppy ribbon cable to PIN1.




RS232 cable

2-6.9 USB2 Header


- This header is for connecting the additional USB cable to provide you two additional USB ports. User can order the additional USB cable from your mainboard dealer and vender.



Additional USB Cable (Optional)



USB2 Header



- When plugging the USB cable into USB2 Header, users must make sure the red wire is connected to the first pin.

2-7 IRQ DESCRIPTION

IRQ	Function Description	Priority
IRQ 0	System Timer	1
IRQ 1	Keyboard Controller	2
IRQ 2	Programmable Interrupt	N/A
IRQ 3	Serial Port (COM 2)	11
IRQ 4	Serial Port (COM 1)	12
IRQ 5		13
IRQ 6	Floppy Disk Controller	14
IRQ 7	Parallel Port (LPT1)	15
IRQ 8	Real Time Clock (RTC)	3
IRQ 9		4
IRQ 10		5
IRQ 11		6
IRQ 12	PS/2 Mouse Port	7
IRQ 13	Coprocessor	8
IRQ 14	Primary IDE Channel	9
IRQ 15	Secondary IDE Channel	10

- Both ISA and PCI expansion cards may require IRQs. System IRQs are available to cards installed in the ISA expansion bus first, then any remaining IRQs are available to PCI cards. Currently, there are two types of ISA cards.
- The original ISA expansion card design, now referred to as “Legacy” ISA card, requires you to configure the card’s jumpers manually and then install it in any available slot on the ISA bus. To see a map of your used and free IRQs in Windows 98, the **Control Panel** in **My Computer**, contains a **System** icon, which gives you a **Device Manager** tab. Double-Clicking on a specific hardware device gives you a **Resources** tab which shows the Interrupt number and address. Double-Clicking **Computers** to see all the interrupts and addresses for your system. Make sure that each ISA device should be assigned to one IRQ respectively. If ISA device share IRQ with any other device, your computer will easily get into trouble.

MEMO

CHAPTER 3

SOFTWARE SETUP

ABOUT SUPPORT CD


- In Support CD, it contains most informations for user's requirement, such as Acrobat Reader, BIOS, User's full version Manual, Driver, Hardware Monitor (if mainboard supports this function), Patch, and Utilities etc. User can browse the CD and get further details in regard of our mainboard. Of course, welcome to vendor's website for the newest release.

This chapter contains the following topics :


- 3-1 VIA CHIPSET DRIVER INSTALLATION (4-IN-1 DRIVER)**
- 3-2 ONBOARD VGA DRIVER INSTALLATION**
- 3-3 AC'97 DRIVER INSTALLATION**

3-1 VIA CHIPSET DRIVER INSTALLATION (4-IN-1 DRIVER)


- 1 • Please put the Support CD provided in your mainboard package into the CD-ROM drive.
- 2 • When a welcome window appears on the screen, users should choose **“Install Driver”**.
- 3 • Click on the **“VIA Chipset Driver”**.
- 4 • Click on the **“4-in-1 driver”**.
- 5 • Click on the **“Install via 4-in-1 driver”** to continue.



- 6 • Press **“Next”** button to continue.




- 7 • Click **“Yes”** to continue.




- 8** • Press select the checkbox as below:
- Bus Master PCI IDE Driver
 - AGP VxD Driver
 - VIA Chipset Function's Registry
 - IRQ Routing Miniport Driver


***Note:** For user who is upgrading VIA Drivers, we recommend to install the 4-in-1 as it will automatically detect and update the necessary drivers.*




- 9** • Select “**Install VIA ATAPI Vendor Support Driver**” checkbox, then click the “**Next**” button to continue.




- 10** • Click on “**Click to enable DMA Mode**” checkbox to enable DMA function, then click the “**Next**” button to continue.



- 11** • Select “Install VIA AGP Vx D” in turbo mode and press **Next** button to continue.



- 12** • Select “Install VIA IRQ Routing Miniport Driver” checkbox, then click the “Next” button to continue.



- 13** • After all these setup procedures have finished, please restart your computer by clicking on **Finish**.

3-2 ONBOARD VGA DRIVER INSTALLATION

- We provide a simple process for user to install VGA driver. Whichever Microsoft Windows operating system user adopts, they have similar installation below.
-
-

3-2.1 Install KLE133 VGA Driver For Windows 95/98/SE

- | | | | |
|----------|---|----------|--|
| 1 | • Please put the Support CD provided in your mainboard package into the CD-ROM drive. | 2 | • When a welcome window appears on the screen, users should choose “ Install Driver ”. |
| 3 | • Click on the “ VIA chipsets Driver ”. | 4 | • Click on the “ VIA KLE133 VGA Driver ” to continue. |
| 5 | • Click on the “ Install VGA Driver for Win95/98/SE ”. | 6 | • Follow the instruction on screen to complete the installation, after which please restart your PC. |
-

3-2.2 Install KLE133 VGA Driver For Windows NT4.0

- | | | | |
|----------|---|----------|--|
| 1 | • Please put the Support CD provided in your mainboard package into the CD-ROM drive. | 2 | • When a welcome window appears on the screen, users should choose “ Install Driver ”. |
| 3 | • Click on the “ VIA chipsets Driver ”. | 4 | • Click on the “ VIA KLE133 VGA Driver ” to continue. |
| 5 | • Click on the “ Install VGA Driver for NT4.0 ”. | 6 | • Follow the instruction on screen to complete the installation, after which please restart your PC. |

3-2.3 Install KLE133 VGA Driver For Windows ME

- 1 • Please put the Support CD provided in your mainboard package into the CD-ROM drive.
 - 2 • When a welcome window appears on the screen, users should choose “**Install Driver**”.
 - 3 • Click on the “**VIA chipsets Driver**”.
 - 4 • Click on the “**VIA KLE133 VGA Driver**” to continue.
 - 5 • Click on the “**Install VGA Driver for Windows ME**”.
 - 6 • Follow the instruction on screen to complete the installation, after which please restart your PC.
-

3-2.4 Install KLE133 VGA Driver Windows 2000


- 1 • Please put the Support CD provided in your mainboard package into the CD-ROM drive.
- 2 • When a welcome window appears on the screen, users should choose “**Install Driver**”.
- 3 • Click on the “**VIA chipsets Driver**”.
- 4 • Click on the “**VIA KLE133 VGA Driver**” to continue.
- 5 • Click on the “**Install VGA Driver for Win2000**”.
- 6 • Follow the instruction on screen to complete the installation, after which please restart your PC.

3-3 AC'97 AUDIO CODEC INSTALLATION

- 1 • Please put the Support CD provided in your mainboard package into the CD-ROM drive.
- 2 • When a welcome window appears on the screen, users should choose “**Install Driver**”.
- 3 • Click on the “**VIA Chipset Driver**”.
- 4 • Click on the “**AC'97 driver**”.



- 5 • Press “**Next**” button to continue.



- 6 • When asking you to install or remove the audio driver, please select “**Install**” and press “**Next**” button to continue.



- 7 • After all the setup process is finished, please restart your computer by clicking on **Finish**.



CHAPTER 4

BIOS SETUP

THE BIOS

- BIOS stands for Basic Input and Output System. It is sometimes called ROM BIOS because it is stored in a Read-Only Memory(ROM) chip on the mainboard. BIOS is the first program to run when you turn on your computer.
- BIOS performs the following functions:
 1. Initializing and testing hardware in your computer (a process called "POST", for Power On Self Test).
 2. Loading and running your operating system.
 3. Helping your operating system and application programs to manage your PC hardware by means of a set of routines called BIOS Run-Time Service.

This chapter contains the following topics :

- 4-1 WHAT IS BIOS SETUP**
- 4-2 HOW TO RUN BIOS SETUP**
- 4-3 WHAT IS CMOS**
- 4-4 WHAT IS POST**
- 4-5 BIOS UPGRADE**
- 4-6 BIOS SETUP**

4-1 WHAT IS BIOS SETUP

- BIOS setup is an interactive BIOS program that you need to run when:
 1. Changing the hardware of your system. (For example: installing a new Hard Disk etc.)
 2. Modifying the behavior of your computer. (For example: changing the system time or date, or turning special features on or off etc.)
 3. Enhancing your computer's behavior. (For example: speeding up performance by turning on shadowing or cache)

4-2 HOW TO RUN BIOS SETUP

- To access BIOS setup menu, press < DEL > key after "POST", and before the OS is loaded. The BIOS usually displays the following message:

Press DEL to enter SETUP

4-3 WHAT IS CMOS

- CMOS is the memory maintained by a battery. The BIOS uses CMOS to store the settings you have selected in SETUP. The CMOS also maintains the internal clock. Every time you turn on your computer, the BIOS Looks into CMOS for the settings you have selected and configures your computer accordingly. If the battery is out of power, the CMOS data will be lost and POST will issue a "CMOS invalid" or "CMOS checksum invalid" message. If this happens, you have to replace the battery and do some proper settings in SETUP.

4-4 WHAT IS POST

- POST is an acronym for Power On Self Test. POST will test all things the BIOS does before the operating system is started. Each of POST routines is assigned a POST code, a unique number which is sent to I/O port 080h before the routine is executed.

4-5 BIOS UPGRADE

- System BIOS is incorporated into a Flash memory component of the mainboard. Flash BIOS allows user to upgrade BIOS without the need to replace an EPROM component.

- The upgrade utility can be loaded on a floppy diskette and used to provide the capability to save, verify, and update the system BIOS. The upgrade utility can be run from a hard disk drive or a network drive.

4-5.1 Before Upgrading BIOS

- It is highly recommended that you save a copy of the original mainboard BIOS along with a Flash EPROM Programming utility (AWDFLASH.EXE) to a bootable floppy disk in case you need to reinstall the BIOS later.

4-5.2 Upgrade Process

Note: Normally, to upgrade BIOS is unnecessary if the system is working fine without any problem. Users should not upgrade the BIOS unless you experience incompatible problems or need to create new features. However, please read all information in this section before upgrading.

“AWDFLASH.EXE” is a Flash EPROM Programming utility that updates the BIOS by uploading a new BIOS file to the programmable flash ROM on the mainboard. This program only works in **DOS environment, the utility can not be executed in win95/98, ME, NT or WINDOWS 2000 environment.**

Upgrading the system BIOS

- Step 1. Please visit the board maker’s website, download latest BIOS file and award flash utility “AWDFLASH.EXE”. The BIOS file format will be *.bin, of which “*” stands for the specific file name.
- Step 2. Create a bootable diskette. Then copy the BIOS file and award flash utility “AWDFLASH.EXE” into the diskette.
- Step 3. Insert the diskette into drive A, reboot your system and boot from the diskette.

- Step 4. Type **awdflash *.bin /sn/py/cc** and then press <Enter> to run BIOS upgrade program. (*.bin depends on your mainboard model and version code. Instead of typing "*", you should type specific file name for your specific mainboard).
- Step 5. Please press <F1> or <F10> to exit or reset your system, **Warning !** If the message **"Write Fail"** appears while Award "FLASH MEMORY WRITER" is verifying Flash memory, just repeat the process. Please DO NOT reset or turn off the system. If the award memory flash utility is not able to update the BIOS successfully, your system may not be able to boot up.
- Step 6. You will need a message "CMOS checksum error-Default loaded" during booting the system. Press to run CMOS setup utility, then reload "LOAD SETUP DEFAULTS" or "**Load Optimized Defaults**" and save this change.




Figure 1 : Award Flash Memory Writer Start Screen




Figure 2 : Award Flash Memory Writer Start Screen

The parameters of AWDFLASH.EXE

/sn: No original BIOS backup

/py: Program flash memory

/cc: Clear CMOS and update data automatically after programming

/r : Reset system after programming

NOTE: *User can type AWDFLASH /? to get further details about parameters.*

Wrong usage of parameter will damage the BIOS information, so that we strongly recommend user to leave parameters alone unless you realize their function.

4-6 BIOS SETUP --- CMOS SETUP UTILITY

4-6.1 CMOS SETUP UTILITY

- This mainboard comes with the AWARD BIOS from AWARD Software Inc. Enter the CMOS Setup Utility Main Menu by:

1. Turn on or reboot your system. After a series of diagnostic checks, the following message will appear:

PRESS TO ENTER SETUP

2. Press the key and the main program screen will appear as follows.

CMOS Setup Utility - Copyright (C) 1984 - 2001 Award Software

▶ Standard CMOS Features	▶ Frequency/Voltage Control
▶ Advanced BIOS Features	Load Optimized Defaults
▶ Advanced Chipset Features	Set Supervisor Password
▶ Integrated Peripherals	Set User Password
▶ Power Management Setup	SAVE & EXIT SETUP
▶ PnP/PCI Configurations	Exit Without Saving
▶ SmartDoc Anti-burn Shield	
Esc : Quit	↑↓→← : Select Item
F10 : Save & Exit Setup	
Time, Date, Hard Disk Type...	

3. Use the arrow keys on your keyboard to select an option, and press <Enter>. Modify the system parameters to reflect the options installed in your system.
4. You may return to the Main Menu anytime by pressing <ESC>.
5. In the Main Menu, "SAVE AND EXIT SETUP" saves your changes and reboots the system, and "EXIT WITHOUT SAVING" ignores your changes and exits the program.

4-6.2 STANDARD CMOS SETUP

- Standard CMOS Setup records some basic system hardware configuration and sets the system clock and error handling. You only need to modify the configuration values of this option if you want to change your system hardware configuration or when the data stored in the CMOS memory gets lost or damaged.

Run the STANDARD CMOS SETUP as follows:

1. Choose "STANDARD CMOS SETUP" from the Main Menu and a screen with a list of options will appear:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Standard CMOS Features

Date (mm:dd:yy)	Tue, May 9 2001	Item Help
Time (hh:mm:ss)	9 : 52 : 15	Menu Level ▶
▶ IDE Primary Master	None	
▶ IDE Primary Slave	None	
▶ IDE Secondary Master	None	
▶ IDE Secondary Slave	None	
Drive A	1.44M, 3.5 in.	
Drive B	None	
Video	EGA/VGA	
Halt On	All,But Keyboard	
Base Memory	640K	
Extended Memory	31744K	
Total Memory	32768K	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys.

Date (mm:dd:yy) The BIOS determines the day of the week from the other date information. This field is for information only.

Press the left or right arrow key to move to the desired field (date, month, year). Press the PgUp or PgDn key to increment the setting, or type the desired value into the field.

Time (hh:mm:ss) The time format is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Press the left or right arrow key to move to desired field. Press the PgUp or PgDn key to increment the setting, or type the desired value into the field.

Primary / Secondary Master / Slave This field records the specifications for all non-SCSI hard disk drives installed in your system. Refer to the respective documentation on how to install the drives.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
IDE Primary Master

IDE HDD Auto-Detection	Press Enter	Item Help
IDE Primary Master	Auto	Menu Level ▶
Access Mode	Auto	
Capacity	10243 MB	
Cylinder	19846	
Head	16	
Precomp	65535	
Landing Zone	19845	
Sector	63	

↑ ↓ → ← : Move Enter : Select +/- / PU / PD : Value F10 : Save ESC : Exit F1 : General Help
F5 : Previous Values F6 : Fail-Safe Defaults F7 : Optimized Defaults

Drive A / Drive B Select this field to the type(s) of floppy disk drive(s) installed in your system. The choices are:
360KB, 5.25in;
1.2MB, 5.25in;
720KB, 3.5in;
1.44MB, 3.5in;
2.88MB, 3.5in;
None.

Video Select the type of primary video subsystem in your computer. The BIOS usually detects the correct video type automatically. The BIOS supports a secondary video subsystem, but you do not select it in setup.

Halt On During the power-on self-test (POST), the computer stops if the BIOS detects a hardware error. You can tell the BIOS to ignore certain errors during POST and continue the boot-up process.

Base Memory Typically 640KB. Also called conventional memory. The DOS operating system and conventional applications use this area.

Extended Memory Above the 1MB boundary. Early IBM personal computers could not use memory above 1MB, but current PCs and their software can use extended memory.

Total Memory This option shows system memory capacity.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.3 ADVANCED BIOS FEATURES

- ADVANCED BIOS FEATURES improves your system performance or sets up system features according to your preference.

Run the ADVANCED BIOS FEATURES as follows:

1. Choose “ADVANCED BIOS FEATURES” from the Main Menu and a screen with a list of options will appear:
2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys. An explanation of the <F> keys follows:

<F1>: “Help” gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Advanced BIOS Features

		Item Help
Virus Warning	Disabled	Menu Level ▶
CPU Internal Cache	Enabled	
External Cache	Enabled	
CPU L2 Cache ECC Checking	Enabled	
Quick Power On Self Test	Enabled	
First Boot Device	Floppy	
Second Boot Device	HDD-0	
Third Boot Device	CDROM	
Boot Other Device	Enabled	
Swap Floppy Drive	Disabled	
Boot Up Floppy Seek	Enabled	
Boot Up NumLock Status	On	
Gate A20 Option	Fast	
Typematic Rate Setting	Disabled	
× Typematic Rate (Chars/Sec)	6	
× Typematic Delay (Msec)	250	
Security Option	Setup	
OS Select For DRAM > 64MB	Non-OS2	
Video BIOS Shadow	Enabled	
C8000-CBFFF Shadow	Disabled	
CC000-CFFFF Shadow	Disabled	
D0000-D3FFF Shadow	Disabled	
D4000-D7FFF Shadow	Disabled	
D8000-DBFFF Shadow	Disabled	
DC000-DFFFF Shadow	Disabled	

↑ ↓ → ← : Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Virus Warning When enabled, you receive a warning message if a program (specifically, a virus) attempts to write to the boot sector or the partition table of the hard disk drive. You should then run an antivirus program. Keep in mind that this feature protects only the boot sector, not the entire hard drive.

***NOTE:** Many disk diagnostic programs that access the boot sector table can trigger the virus warning message. If you plan to run such a program, we recommend that you disable the virus warning.*

**CPU Internal Cache/
External Cache** Cache memory is additional memory that is much faster than conventional DRAM (system memory). CPUs from 486-type up contain internal cache memory, and most, but not all, modern PCs have additional (external) cache memory. When the CPU requests data, the system transfers the requested data from the main DRAM into cache memory, for faster access by the CPU.

**CPU L2 Cache ECC
Checking** When you select *Enabled*, it will speed up memory checking when the external cache contains ECC SRAMs.
The choices: Enabled; Disabled.

**Quick Power On Self
Test** Select Enabled to reduce the amount of time required to run the power-on self-test (POST). A quick POST skips certain steps. We recommend that you normally enable quick POST.

**First/Second/Third/
Other Boot Device** The BIOS attempts to load the operating system from the devices in the sequence selected in these items. The choices: Floppy; LS/ZIP; HDD; SCSI; CDROM; Disabled.

Swap Floppy Drive When enabled, floppy drives A and B will be exchanging without any physical connection and modification on the cables.

Boot Up Floppy Seek When enabled, the BIOS tests (seeks) floppy drives to determine whether they have 40 or 80 tracks. Only 360-KB floppy drives have 40 tracks; drives with 270KB, 1.2MB, and 1.44MB capacity all have 80 tracks. Because very few modern PCs have 40-track floppy drives, we recommend that you set this field to disabled to save time.

Boot Up NumLock Status Toggle between On or Off to control the state of the NumLock key when the system boots. If On, the numeric keypad is in numeric mode. If off, the numeric keypad is in cursor control mode.

Gate A20 Option Gate A20 refers to the way the system addresses memory above 1 MB (extended memory). When set to *Fast*, the system chipset controls Gate A20. When set to *Normal*, a pin in the keyboard controller controls Gate A20. Setting Gate A20 to Fast improves system speed, particularly with OS/2 and Windows.

Typematic Rate Setting When *Disabled*, the following two items (Typematic Rate and Typematic Delay) are irrelevant. Keystroke repeats at a rate determined by the keyboard controller in your system. When *Enabled*, you can select a typematic rate and typematic delay.

Typematic Rate (Chars / Sec) When the typematic rate setting is enabled, you can select a typematic rate (the rate at which character repeats when you hold down a key) of 6, 8, 10, 12, 15, 20, 24, or 30 characters per second.

Typematic Delay (Msec) Choices: 250; 500; 750; 1000. This option sets the time interval for displaying the first and the second characters. If enabled, the time interval is optional.

Security Option If you have set a password, select whether the password is required every time the System boots, or only when you enter setup.
The choices: system; setup.

OS Select For DRAM > 64MB Select OS2 only if you are running OS/2 operating system with greater than 64MB of RAM on your system.

Video BIOS Shadow Performance will be improved by copying Video BIOS to Shadow RAM.

C8000-CBFFF to DC000-DFFFF Shadow These options are used to shadow other expansion card ROMs.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.4 ADVANCED CHIPSET FEATURES

- ADVANCED CHIPSET FEATURES is used to modify the values of chipset buffers. These buffers control the system options.

Run the ADVANCED CHIPSET FEATURES as follows:

1. Choose “ADVANCED CHIPSET FEATURES” from the Main Menu and a list of option will appear:
2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys. An explanation of the <F> keys follows:

<F1>: “Help” gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Advanced Chipset Features

		Item Help
DRAM Timing By SPD	Enabled	Menu Level ▶
DRAM Clock	133M	
SDRAM Cycle Length	3	
Bank Interleave	Disabled	
DRAM Drive Strength	Auto	
×DRAM Drive Value	2F	
Memory Hole	Disabled	
PCI Master Pipeline Req	Enabled	
P2C/C2P Concurrency	Disabled	
Fast R-W Turn Around	Disabled	
System BIOS Cacheable	Disabled	
Video RAM Cacheable	Disabled	
AGP Aperture Size	64M	
AGP Mode	4X	
AGP Driving Control	Auto	
AGP Driving Value	DA	
×AGP Fast Write	Disabled	
OnChip USB	Enabled	
OnChip USB 2	Enabled	
USB Keyboard Support	Disabled	
OnChip Sound	Auto	
OnChip Modem	Auto	
CPU to PCI Write Buffer	Enabled	
PCI Dynamic Bursting	Enabled	
PCI Master 0 WS Write	Enabled	
PCI Delay Transaction	Disabled	
PCI#2 Access #1 Retry	Enabled	
AGP Master 1 WS Write	Disabled	
AGP Master 1 WS Read	Disabled	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

DRAM Timing by SPD When this item Enabled, DRAM Timing is set by SPD. SPD (Serial Presence Detect) is located on the memory modules, BIOS reads information coded in SPD during system boot up.

DRAM Clock The value represents the performance parameters of the installed memory chips (DRAM). Do not change the value from the factory setting unless you install new memory that has a different performance rating .

SDRAM Cycle Length Time Select CAS latency time in HCLKs of 2 or 3. The system designer already set the values. Do not change the values from the default value unless you change specifications of the installed DRAM or the installed CPU.

Bank Interleave The choices: Disabled; 2 Bank; 4 Bank.

DRAM Drive Strength Leave this item with Auto mode.
The choices: Auto; Manual.

DRAM Drive Value When “DRAM Drive Strength” is set to “Auto”, this item will be unable to be selected. We don't recommend user to adjust this item.

Memory Hole In order to improve performance, certain space in memory is reserved for ISA cards. This memory must be mapped into the memory space below 16MB.
The choices: 15M-16M; Disabled.

PCI Master Pipeline Req Use default setting.

P2C/C2P Concurrency This item allows you to enable/disable the PCI to CPU, CPU to PCI concurrency.
The choices: Enabled; Disabled.

Fast R-W Turn Around This item controls the DRAM timing. It allows you to enable / disable the fast read / write turn around.
The choices: Enabled; Disabled.

System BIOS Cacheable selecting Enabled allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance.

Video RAM Cacheable selecting Enabled allows caching of the video memory (RAM) at A0000h to AFFFFh, resulting in better video performance.
However, check your AGP manual to find out if any compatibility problem exists.

AGP Aperture Size Series of options are available: 4, 8, 16, 32, 64, 128 or 256 MB. Memory mapped and graphics data structures can reside in a Graphics Aperture. This area is like a linear buffer. BIOS will automatically report the starting address of this buffer to the O.S.
The default setting is 64MB.

AGP Mode This item allows you to select AGP mode.
The choices: 1X; 2X; 4X.

AGP Driving Control This item allows you to adjust the AGP driving force. Choose Manual to key in a AGP Driving Value in the next selection. This field is recommended to set in Auto for avoiding any error in your system.
The choices: Manual; Auto.

AGP Driving Value This item allows you to adjust the AGP driving force.
The choices: Min=0000 ~ Max=00FF.

- AGP Fast Write** This item will enable the AGP model into fast write mode. If your graphics card does not support this function, please do not enable this function.
- OnChip USB/USB2** This should be enabled if our system has a USB installed on the system board and you wish to use it. Even when so equipped, if you add a higher performance controller, you will need to disable this feature. The choices: Enabled; Disabled.
- USB Keyboard Support** Enable function when the USB keyboard is being used . When the AT keyboard is being used, choose disabled.
- OnChip Sound** Enabled: Turn on AC'97 codec chip controller.
Disabled: Turn off AC'97 codec chip controller or user can plug external add-on sound card.
- OnChip Modem** Select Auto to use the on-chip Modem capability of your system. This field must be Disabled, if there is NO AMR modem card installed.
The choices: Auto; Disabled.
- CPU to PCI Write Buffer** When this field is Enabled, writes from the CPU to the PCI bus are buffered, CPU speed runs faster than PCI bus. When Disabled, the writes are not buffered and the CPU must wait until the write is complete before starting another write cycle.
The choices: Enabled; Disabled.
- PCI Dynamic Bursting** When Enabled, every write transaction goes to the write buffer. Burstable transactions then burst on the PCI bus and nonburstable transactions don't.
The choices: Enabled; Disabled.

PCI Master 0 WS Write When Enabled, writes to the PCI bus are executed with zero wait states.
The choices: Enabled; Disabled.

Memory Parity/ECC Check This item enabled to detect the memory parity and Error Checking & Correcting.
The choices: Enabled; Disabled.

PCI Delay Transaction Leave this field at default

PCI #2 Access #1 Retry Leave this field at default

AGP Master 1 ws write Leave this field at default

AGP Master 1 ws read Leave this field at default

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.5 INTEGRATED PERIPHERALS

- INTEGRATED PERIPHERALS option allows you to get some information inside your system when it is working.

Run the INTEGRATED PERIPHERALS as follows:

1. Choose "INTEGRATED PERIPHERALS" from the Main Menu and a list of options will appear:
2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys. An explanation of the <F> keys follows:

<F1>: "Help" gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
 Integrated Peripherals

		Item Help
On-Chip IDE Channel0	Enabled	
On-Chip IDE Channel1	Enabled	Menu Level ▶
IDE Prefetch Mode	Enabled	
Primary Master PIO	Auto	
Primary Slave PIO	Auto	
Secondary Master PIO	Auto	
Secondary Slave PIO	Auto	
Primary Master UDMA	Auto	
Primary Slave UDMA	Auto	
Secondary Master UDMA	Auto	
Secondary Slave UDMA	Auto	
Init Display First	PCI Slot	
IDE HDD Block Mode	Enabled	
Onboard FDD Controller	Enabled	
Onboard Serial Port 1	Auto	
Onboard Serial Port 2	Auto	
UART 2 Mode	Standard	
× IR Function Duplex	Half	
× TX, RX inverting enable	No, Yes	
Onboard Parallel Port	378/IRQ7	
Onboard Parallel Mode	Normal	
× ECP Mode Use DMA	3	
× Parallel Port EPP Type	EPP1.9	
Onboard Legacy Audio	Enabled	
Sound Blaster	Disabled	
SB I/O Base Address	220H	
SB IRQ Select	IRQ 5	
SB DMA Select	DMA 1	
MPU-401	Disabled	
MPU-401 I/O Address	330-333H	
Game Port (200-207H)	Enabled	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

On-Chip IDE channel 0/1 The chipset contains a PCI IDE interface with support from two IDE channels. Select Enabled to activate the first and/or the second IDE interface. Select Disabled to inactivate an interface if you install a primary and/or second add-on IDE interface.
The choices: Enabled; Disabled.

IDE Prefetch Mode The on-board IDE drive supports IDE perfecting for faster drive accesses. If the IDE device doesn't support perfecting, set this field to Disabled.
The choices: Enabled; Disabled.

Primary Master / Slave PIO Secondary Master / Slave PIO Choose Auto or Mode 0~4. The BIOS will detect the HDD mode type automatically when you choose Auto. You need to set to a lower mode than Auto when your hard disk becomes unstable.
The choices: Auto; Mode 0; Mode 1; Mode 2; Mode 3; Mode 4.

Primary Master / Slave UDMA Secondary Master / Slave UDMA Ultra DMA33/66/100 implementation is possible only if your IDE hard drive supports it, if the operating environment includes a DMA drive, and if your system software supports Ultra DMA33/66/100. Select "Auto" to enable BIOS support.
The choices: Auto; Disabled.

Init Display First Initialize the AGP video display before initializing any other display device on the system. Thus the AGP display becomes the primary display.

IDE HDD Block Mode Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/write per sector the drive can support.
The choices: Enabled; Disabled.

- Onboard FDC Controller** Select Enabled if your system has a floppy drive controller (FDC) installing in the system board and you want to use it. If you install add-in FDC or the system has no floppy drive, select Disabled in this field.
The choices: Enabled; Disabled.
- Onboard Serial Port 1 / Port 2** Select a logical COM port name and matching address for the first and second serial ports. Select an address and corresponding interrupt for the first and second serial ports.
- UART 2 Mode** This item allows you to select which mode for the Onboard Serial Port 2.
The choices: Standard; HPSIR; ASKIR
- IR Function Duplex** This item allows you to select the IR half / full duplex function.
The choices: Half; Full.
- TX, RX inverting enable** This item allows you to enable the TX, RX inverting which depends on different H/W requirement. This field is not recommended to change its default setting.
The choices: "No, No"; "No, Yes"; "Yes, No"; "Yes, Yes".
- Onboard Parallel Port** This item allows you to determine onboard parallel port controller I/O address setting.
The choices: 378H/IRQ7; 278H/IRQ5; 3BC/IRQ7; Disabled.
- Onboard Parallel Mode** Select an operating mode for the on-board parallel (printer) port. Select Normal, Compatible, or SPP unless you are certain your hardware and software both support one of the other available modes.

ECP Mode Use DMA Select a DMA channel for the port.

Parallel Port EPP Type Select EPP port type 1.7 or 1.9
The choice: EPP1.7, 1.9.

Onboard Legacy Audio This field controls the onboard audio.

- Sound Blaster
- SB I/O Base Address
- SB IRQ Select
- SB DMA Select
- MPU-401
- MPU-401 I/O Address
- Game Port (200-207H)

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.6 POWER MANAGEMENT SETUP

- POWER MANAGEMENT SETUP allows you to set the system’s power saving functions.

Run the POWER MANAGEMENT SETUP as follows:

1. Choose “POWER MANAGEMENT SETUP” from the Main Menu and a list of options will appear:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Power Management Setup

ACPI Function	Enabled	Item Help
▶ Power Management	Press Enter	Menu Level ▶
ACPI Suspend Type	S1(POS)	
PM Control by APM	Yes	
Video Off Option	Suspend -> Off	
Video Off Method	V/H SYNC+Blank	
MODEM Use IRQ	3	
Soft-Off by PWRBTN	Instant-Off	
State After Power Failure	Auto	
▶ Wake Up Events	Press Enter	

↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys. An explanation of the <F> keys follows:

<F1>: “Help” gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

ACPI Function Select Enabled only if your computer's operating system supports the Advanced Configuration and Power Interface (ACPI) specification.

Power Management

- When this option is chosen, the following item appears for user's configuration.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Power Management

Power Management	User Define	Item Help
HDD Power Down	Disable	Menu Level ▶
Doze Mode	Disable	
Suspend Mode	Disable	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

- * **Power Management** This option allows you to select the type (or degree) of power saving for Doze, Standby, and Suspend modes.

This table describes each power management mode:

Max Saving	Maximum power savings. Only Available for SL CPUs. Inactivity period is 1 minute in each mode.
User Define	Set each mode individually. Select time-out period in the section for each mode stated below.
Min Saving	Minimum power savings. Inactivity period is 1 hour in each mode (except the hard drive).

*** HDD Power Down** When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

*** Doze Mode** When enabled and after the set time of system inactivity, the CPU clock will run at slower speed while all other devices still operate at full speed.

*** Suspend Mode** After the selected period of system inactivity, the chipset enters a hardware suspend mode, stopping the CPU clock and possibly causing other system devices to enter power management modes.

ACPI Suspend Type This item allows you to select the ACPI suspend type. You can select S3(STR) for suspending to DRAM or S1(POS) for power on suspend under Windows 98 ACPI mode.
The choices: S1(POS), S3(STR).

PM Control by APM When enabled, an Advanced Power Management device will be activated to enhance the Max. Power Saving mode and stop the CPU internal clock, If Advanced Power Management (APM) is installed on your system, selecting Yes gives better power savings. If the Max. Saving is not enabled, this will be present to No.

Video Off Option When enabled, this feature allows the VGA adapter to operate in a power saving mode.

Always On	Monitor will remain on during power saving modes.
Suspend -->Off	Monitor blanked when the systems enters the Suspend mode.
All Modes -->Off	Monitor blanked when the system enters either Suspend or Standby modes.

Video Off Method This determines the manner by which the monitor is blanked.

V/H SYNC + Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS Supports	Select this option if your monitor supports the Display Power Management Signaling (DPMS) standard of the Video Electronics Standards to select video power management values.

MODEM Use IRQ Name the interrupt request (IRQ) line assigned to the modem (if any) on your system. Activity of the selected IRQ always awakens the system.
The choices: 3; 4; 5; 7; 9; 10; 11; NA.

Soft-Off by PWRBTN When Enabled, turning the system off by pressing the on/off button places the system in a very low-power-usage state.

State After Power Failure This field lets you determine the state that your PC returns to after a power failure.
The choices: On; Off; Auto.

Wake Up Events

- When this option is chosen, the following item appears for user's configuration.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Wake Up Events

VGA	OFF	Item Help
LPT & COM	LPT/COM	Menu Level ▶
HDD & FDD	ON	
PCI Master	OFF	
Wake Up On LAN/Ring	Disabled	
RTC Alarm Resume	Disabled	
× Date (of Month)	0	
× Resume Time (hh:mm:ss)	0 0 0	
Primary INTR	ON	
▶ IRQ Activity Monitoring	Press Enter	

↑ ↓ → ← : Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

* **VGA** When Enabled, you can set the VGA awakens the system

* **LPT & COM** When LPT & COM is ON, any activity from one of the listed system peripheral devices or IRQs wakes up the system.

* **HDD & FDD** When HDD & FDD is ON, any activity from one of the listed system peripheral devices wakes up the system.

* **PCI Master** When PCI Master is ON, any activity from one of the listed system peripheral devices wakes up the system.

* **Wake Up On LAN/Ring** An input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state.
The choices: Enabled; Disabled.

* **RTC Alarm Resume** When Enabled, you can set the data and time at which the RTC (Real Time Clock) alarm awakens the system from suspend mode.
The choices: Disabled (default); Enabled.

* **Date (of Month)** Set a certain date when RTC Alarm Resume option is Enabled to awaken the system. This option is concurrent with Resume Time option.

* **Resume Time (hh:mm:ss)** Set a certain time when RTC Alarm Resume option is Enabled to awaken the system. This option is concurrent with Date option.

* **Primary INTR** Leave this field at default

* IRQ Activity Monitoring

- When this option is chosen, the following item appears for user's configuration.

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
 IRQ Activity Monitoring

IRQ 3 (COM2)	Enabled	Item Help
IRQ 4 (COM1)	Enabled	Menu Level ▶
IRQ 5 (LPT2)	Enabled	
IRQ 6 (Floppy Disk)	Enabled	
IRQ 7 (LPT1)	Enabled	
IRQ 8 (RTC Alarm)	Disabled	
IRQ 9 (IRQ2 Redir)	Disabled	
IRQ 10 (Reserved)	Disabled	
IRQ 11 (Reserved)	Disabled	
IRQ 12 (PS/2 Mouse)	Enabled	
IRQ 13 (Coprocessor)	Enabled	
IRQ 14 (Hard Disk)	Enabled	
IRQ 15 (Reserved)	Disabled	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

IRQ Activity Monitoring - The following is a list of IRQ's (Interrupt Requests), which can be exempted much as the COM ports and LPT ports above can. When an I/O device wants to gain the attention of the operating system, it signals this by causing an IRQ to occur. When the operating system is ready to respond to the request, it interrupts itself and performs the service. When set On, activity will neither prevent the system from going into a power management mode nor awaken it.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.7 PNP / PCI CONFIGURATION

- PNP/PCI CONFIGURATION allows you to modify the system's power saving functions.

Run the PNP/PCI CONFIGURATION as follows:

1. Choose "PNP/PCI CONFIGURATION" from the Main Menu and a screen with a list of options will appear:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
PnP/PCI Configurations

PNP OS Installed	No	Item Help
Reset Configuration Data	Disabled	Menu Level ▶
Resources Controlled By	Auto(ESCD)	
× IRQ Resources	Press Enter	
× DMA Resources	Press Enter	
PCI/VGA Palette Snoop	Disabled	
Assign IRQ For VGA	Enabled	
Assign IRQ For USB	Enabled	
PCI SLOT 1/5 IRQ Assigned	Auto	
PCI SLOT 2/6 IRQ Assigned	Auto	
PCI SLOT 3 IRQ Assigned	Auto	
PCI SLOT 4 IRQ Assigned	Auto	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys. An explanation of the <F> keys follows:

<F1>: "Help" gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

PNP OS Installed Select Yes if the system operating environment is Plug-and-Play aware (e.g., Windows95).

***NOTE:** BIOS will automatically disable all PnP resources except the boot device card when you select Yes on Non-PnP operating system.*

Reset Configuration Data Normally, you leave this Disabled. Select Enabled to reset Extended System Configuration Data (ESCD), when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the operating system cannot boot.

Resource Controlled By The Plug and Play AwardBIOS can automatically configure all the boot and Plug and Play-compatible devices. If you select *Auto*, all the interrupt request (IRQ) and DMA assignment fields disappear, as the BIOS automatically assigns them.

IRQ Resources Press Enter. Please refer to the list below:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
 IRQ Resources

IRQ-3 assigned to	PCI/ISA PnP	Item Help
IRQ-4 assigned to	PCI/ISA PnP	Menu Level ▶
IRQ-5 assigned to	PCI/ISA PnP	
IRQ-7 assigned to	PCI/ISA PnP	
IRQ-9 assigned to	PCI/ISA PnP	
IRQ-10 assigned to	PCI/ISA PnP	
IRQ-11 assigned to	PCI/ISA PnP	
IRQ-12 assigned to	PCI/ISA PnP	
IRQ-14 assigned to	PCI/ISA PnP	
IRQ-15 assigned to	PCI/ISA PnP	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
 F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

DMA Resources Press Enter. Please refer to the list below:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
DMA Resources

DMA-0 assigned to	PCI/ISA PnP	Item Help
DMA-1 assigned to	PCI/ISA PnP	Menu Level ▶
DMA-3 assigned to	PCI/ISA PnP	
DMA-5 assigned to	PCI/ISA PnP	
DMA-6 assigned to	PCI/ISA PnP	
DMA-7 assigned to	PCI/ISA PnP	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

PCI/VGA Palette Snoop This option allows the BIOS to preview VGA status, and to modify the information delivered from the feature Connector of the VGA card to MPEG card. This option can solve the display inversion to black after you have used MPEG card.

Assign IRQ for VGA Select *Enabled* if you system has a VGA controller and you have one or more VGA devices connected. If you are not using your system's VGA controller, select *Disabled* to free the IRQ resource.

Assign IRQ for USB Select *Enabled* if you system has a USB controller and you have one or more USB devices connected. If you are not using your system's USB controller, select *Disabled* to free the IRQ resource.

PCI SLOT1/5, 2/6, 3, 4 IRQ Assigned These options allow you to assign an IRQ for each PCI SLOT and this is a useful function when you want to fix the IRQ conflict for a specific device. The options are available: Auto, 3, 4, 7, 9, 10, 11.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.8 SMARTDOC ANTI-BURN SHIELD

- This section helps you to get more information about your system including CPU temperature, FAN speed and voltage. It is recommended that you contact with your mainboard supplier to get proper values about the setting of the CPU temperature.

Run the “SMARTDOC ANTI-BURN SHIELD” as follows:

1. Choose “SMARTDOC ANTI-BURN SHIELD” from the Main Menu and a screen with a list of options will appear:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
SmartDoc Anti-Burn Shield

CPUFan Warning Speed	Disabled	Item Help
Shutdown For CPUFan	Disabled	Menu Level ▶
Current CPUFAN1 Speed	5120 RPM	
Current CPUFAN2 Speed	0 RPM	
Vcore	1.53V	
VDD	3.34V	
3.3V	3.28V	
5V	5.00V	
12V	11.76V	

↑ ↓ → ← :Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys.

<F1>: “Help” gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

CPUFan Warning Speed This feature prevents the malfunction of the CPU cooling fan. When CPU cooling fan speed lower than value you selected in this field, the BIOS will send out sequence of beeps sound or send out a warning message “**Your CPU FAN speed is too slow**”.

Shutdown For CPUFan This feature prevents your CPU damaged by over heat, but the difference between features “**Shutdown For Temperature**” and “**Shutdown For CPUFan**” is that BIOS detects CPU cooling fan speed not CPU Temperature in this field, when CPU FAN speed lower than the value that you select in this field, the BIOS will shutdown your system within 3 seconds.

Warning!!! Do not enable feature “Shutdown For CPUFan” without CPU cooling fan connecting to onboard fan connector FAN1; otherwise, your system will not be able to boot.

Current CPUFAN1 Speed Shows current CPUFAN1 speed. The fan must provide rotary pulse. (Normally these types of fan have a three-wire connector)

Current CPUFAN2 Speed Show current CPUFAN2 speed. The fan must provide rotary pulse. (Normally these types of fan have a three-wire connector)

Vcore/VDD/3.3V/5V/12V Show power supply actual voltage value.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.9 FREQUENCY/VOLTAGE CONTROL

Run the “FREQUENCY/VOLTAGE CONTROL” as following:

1. Choose “FREQUENCY/VOLTAGE CONTROL” from the Main Menu and a screen with a list of options will appear:

CMOS Setup Utility - Copyright (C) 1984-2001 Award Software
Frequency Control

Redstorm Overclocking Tech	Press Enter	Item Help
Auto Detect DIMM/PCI Clk	Enabled	Menu Level ▶
Spread Spectrum Modulated	Disabled	
CPU Host/PCI Clock	Default	

↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

2. Use one of the arrow keys to move between options and modify the selected options by using PgUp / PgDn / + / - keys.

<F1>: “Help” gives options available for each item.

<F5>: Get the previous values. These values are the values with which the user starts the current session.

<F6>: Load all options with the BIOS default values.

<F7>: Load all options with the Setup default values.

RedStorm Overclocking Tech Press “Enter” to execute this function, by which BIOS will detect CPU Frequency, until the unacceptable one is reached. BIOS will then stop and reboot automatically with the optimal CPU Frequency. If system does not reboot after Frequency detection, user should reboot system manually.

Auto Detect DIMM/PCI CLK To reduce the occurrence of electromagnetic interference (EMI), the BIOS detects the presence or absence of components in DIMM and PCI slots and turns off system clock generator pulses against empty slots.

Spread Spectrum Modulated When the system clock generator pulses, the extreme values of the pulse generate excess EMI. Enabling pulse spectrum spread modulation changes the extreme values from spikes to flat curves, thus reducing EMI. This benefit may in some cases be outweighed by problems with timing-critical devices, such as a clock-sensitive SCSI device.

CPU Host/PCI Clock Select Default or select a timing combination for the CPU and the PCI bus. When set to Default, the BIOS uses the actual CPU and PCI bus clock values.

3. Press <ESC> to return to the Main Menu when you finish setting up all items.

4-6.10 LOAD OPTIMIZED DEFAULTS

- When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

`Load Optimized Defaults (Y/N) ? N "`

“Y” is for “Yes”, and “N” is for “No”.

Pressing “Y” loads the BIOS default values that are factor settings for optimal performance of system operations.

4-6.11 SET SUPERVISOR / USER PASSWORD

- These two options allow you to set your system passwords. Normally, the supervisor has a higher priority to change the CMOS setup option than the users. The way to set up the passwords for both Supervisor and Users are as follows:

1. Choose "Change Password" in the Main Menu and press <Enter>. Then following message appears:

`"Enter Password : "`

2. The first time you run this option, enter your password up to 8 characters and press <Enter>. (The screen does not display the entered characters.)
3. After you enter the password, the following message appears prompting you to confirm the password:

`"Confirm Password : "`

4. Enter the same password "exactly" the same as you have just typed to confirm the password and press <Enter>.
5. Move the cursor to Save & Exit Setup to save the password.
6. If you need to delete the password entered before, choose the Supervisor Password and press <Enter>. It will delete the password that you have entered before.
7. Move the cursor to Save & Exit Setup to save the option you have just configured; otherwise the old password will still be there the next time you turn your system on.
8. Press <Enter> to exit to the Main Menu.

NOTE: *If you forget or lose the password, the only way to access the system is to clear the CMOS RAM. All setup informations will be lost and you need to run the BIOS setup program again.*

4-6.12 SAVE & EXIT SETUP

- SAVE & EXIT SETUP allows you to save all modifications you have specified into the CMOS memory. Highlight this option on the Main Menu and the following message appears:

```
  ` SAVE to CMOS and EXIT (Y/N) ? Y `
```

“Y” is for “Yes”, and “N” is for “No”.

Press <Enter> key to save the configuration changes.

4-6.13 EXIT WITHOUT SAVING

- EXIT WITHOUT SAVING option allows you to exit the Setup Utility without saving the modifications that you have specified. Highlight this option on the Main Menu and the following message appears:

```
  ` Quit Without Saving (Y/N) ? N `
```

“Y” is for “Yes”, and “N” is for “No”.

You may change the prompt to “Y” and press <Enter> key to leave this option .



APPENDICES


APPENDIX-1 TECHNICAL TERMS
**APPENDIX-2 IDENTIFYING BIOS VERSION/
BIOS PART NUMBER**
**APPENDIX-3 IDENTIFYING MAINBOARD
MODEL NUMBER**

APPENDIX-1 TECHNICAL TERMS

Technical Terms Introduction	
Tech Term	Meaning
AGP	Accelerated Graphic Port
AMR	Audio Modem Riser
ACR	Advanced Communication Riser
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCE	Extended System Configuration Data
ECC	Error Check and Correct
EPP	Enhanced Parallel Port
FDD	Floppy Disk Device
IDE	Integrated Dual Channel Enhanced
IRQ	Interrupt ReQuest
I/O	Input/Output
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Local Emitting Diode
MHz	Megahertz
PNP	Plug & Play
USB	Universal Serial Bus
VCM	Virtual Channel Memory


APPENDIX-2 IDENTIFYING BIOS VERSION AND BIOS PART NUMBER

- When you boot up your computer, you may see a screen which shows your computer is phoenixnet™ enabled. Please see Picture-1 below for an illustration.
- When the screen shows up press “Tab” key for BIOS information.



Picture-1

- See Picture-2 below for BIOS version and BIOS part number identification.





Picture-2

1. BIOS VERSION
example: REV T2.1
2. BIOS ID STRING
example: 6A69RSNCC

APPENDIX-3 IDENTIFYING MAINBOARD MODEL NUMBER

- Usually the mainboard model number is labeled on the side of ISA or PCI slot. Please see the picture below for an illustration:



1. MAINBOARD MODEL NUMBER
example: SL-65KV2
2. MAINBOARD SERIAL NUMBER
example: 0012000T005679

MEMO
