


P2BLX

rev. A+



■ Square denotes pin 1

DIP Switch Settings of the Processors

CPU Frequency	Ext. System Bus Clock	Frequency Ratio	SW1
233MHz	66MHz	3.5x	
266MHz	66MHz	4x	
300MHz	66MHz	4.5x	
333MHz	66MHz	5x	
366MHz	66MHz	5.5x	
400MHz	66MHz	6x	
433MHz	66MHz	6.5x	



Black rectangle denotes the part that is protruding, the "adjustable" switch



In the example above:

- Switch 1: On
- Switch 2: On
- Switch 3: Off
- Switch 4: On

Note:

The voltage regulator will automatically be set according to the voltage of the processor.

JPI (Wake-On-Keyboard/Mouse) - 1-2 On: Disable (default); 2-3 On: Enable
If JPI is set to 2-3 On - enabled, make sure "Keyboard/Mouse Power On" in the Integrated Peripherals setup of the Award BIOS is set accordingly.

Jumper JPI2 (CMOS Clear) - 1-2 On: Normal (default); 2-3 On: Clear CMOS Data
Before clearing the CMOS data, make sure to power-off your system and unplug the power cord.