

Part Name	Part No.
IR BOARD ASS'Y V5.0 320	77-32004-00X
CABLE FOR IR TO M/B V1.0 320	43-32008-001
POWER BOARD ASS'Y V4.0 320	77-32001-00X
MAIN BOARD ASS'Y V4.0 320	77-32000-11X
CD-ROM ASS'Y TOS 24X 320	79-3200C-210
CABLE FOR MODEM TO M/B V2.0 320	43-32007-002
BOTTOM CASE	39-32006-003
SPA EK ASS'Y V3.0 320	79-3200S-042
RUBBER FOOT, SILICONE 320	47-32001-010
LCD LOCK BUTTON PC+ABS 320	39-32017-000
BATTERY LOCK KNOB	39-32014-000
BATTERY LOCK , POM 320	39-32010-001
IRDA LENS, GEPC 960A	39-96A31-000
CD-ROM LOCK, POM 320	39-32009-000
CD-ROM LOCK KNOB	39-32013-000
HDD BRACKET ASS'Y 320	79-3200H-032
FAN+CON.35*35*7MM5V 0.12V 0.032M3/MIN	23-A3518-034
I/O DOOR	39-32016-002
TOP HEAT SINK, ASS'Y 320	79-3200K-020
SPEAKER (R) SPONGE 320	47-32001-070
BOTTOM CASE MYLAR	4032001-000
BOTTOM HEAT SINK AL 320	33-32013-000
RAM COVER ASS'Y	79-3200R-030
LCD HOOK PUSH. POM 320	39-32012-000
K/B SPONGE	47-32001-120
SHIELDING PLATE FOR I/O BRACKET	33-32027-000
KEYBOARD (win95)	80-32000-012
LED COVER	39-32031-011
HINGER COVER (R)	39-32019-002
LED TOP LENS (R)	39-32025-011
LED TOP LENS (L)	39-32025-001
MICRO PHONE	79-32001-052
HINGER COVER (L)	39-32029-002
TOP CASE	39-32005-002
CABLE FOR CLICK BOARD	43-32016-001
CABLE FOR POWER TO T/P V1.0 320	43-32009-001
TOUCHPAD SHIELDING ASS'Y	79-320TP-002
TOUCHPAD BUTTOM (L)	39-32008-001
LED FRONT LENS	39-32026-001
CLICK BOARD ASS'Y V4.0	77-32003-014
TOUCHPAD BUTTOM (R)	39-32008-011
CD-ROM BRACKET 320	33-32007-000
CLICK BOARD HIMILON	47-32001-050
LCD FRONT COVER 12.1"	39-32001-002
LCD F-CVR RUBBER	47-32001-020
LCD SAN./TM121SV-02L04 S-TFT	50-422216-151
INVERTER CARD ASS'Y V2.0 320	77-32002-003
LCD SAN. 12.1 SPONGE 320	47-32001-100

LCD BRACKET (R) FOR 12.1	33-32002-001
CABLE FOR SA.121 AND INVERTER	43-32021-002
LCD BRACKET (FRONT) SUS320	33-32004-002
MAGNETNI-COATING	25-90002-003
HINGE(R) ASS'Y 320	79-3200Y-013
HINGE(L) ASS'Y 320	79-3200Y-023
LCD BRACKET(L) FOR FOR 12.1	33-32003-001
LCD BACK COVER for SANYO	39-32003-002
DISPLAY LABEL FOR BACK COVER	by customer
SCREW,M2.0*6.0L,K1,BZ,ICT	35-B6120-6RO
LCD FRONT COVER 13.3"	39-32002-002
SCREW,M2.5*0.45P*6L,K1,BN,ICT,NY	35-B9125-6RO
LCD F-CVR RUBBER	47-32001-020
LCD HYU.13.3" SPONGE	47-32001-090
LCD,T,HY,HT13X13-203,13.3	50-43326-135
INVERTER CARD ASS'Y V2.0 320	77-32002-003
INVERTER KAPTON, KAPTON 320	40-32011-000
ELECTRIC SHOCK CAUTION 82H	45-82004-000
INVERTER MYLAR 320	40-32006-002
SCREW,M2*3L,K1,BZ,ICT,NY	35-B6120-3RO
COAXIAL CABLE FOR HYU.	43-32023-002
SCREW,M2.0*4.0L.K1.BZ,ICT	35-B6120-4RO
MAGNET NI-COATING	25-90002-003
LCD MAGNET BRACKET	33-32023-000
LCD BRACKET(L) FOR 13.3"	33-32017-000
SCREW,M2.5*4L,K1,BNI,ICT,NY	35-B9125-4RA
HINGE(L) ASS'Y 320	79-3200Y-023
LCD BRACKET(R) FOR 13.3"	33-32016-000
HINGE(R) ASS'Y 320	79-3200Y-013
LCD BACK COVER H=7.5 FOR HYU	39-32004-003
DISPLAY LABLE FOR BACK COVER	by customer
LCD 13.3" BOTTOM SPONGE	47-32001-110
EMI RUBBER	47-32004-060
EMI GASKETS	47-32004-070
CONDUCTIVE CLOTH TYPE L60*50	47-26804-000
CONDUCTIVE CLOTH TYPE L80*30	47-32004-050
LCD KAPTON FOR HYU 13.3"	40-32015-000
CD-ROM BEZEL ASS'Y FOR TOS.	79-3200C-220
CD-ROM HOUSING	39-32021-001
CD-ROM 5.25" 24X 12.7MM XM-1902B	84-14002-A12
SCREW M2.0*2.6L K1 BZ ICT	35-B6120-2R5
CD/DVD-ROM CVT BOARD	77-32005-003
SCREW M2.0*5L K1 BZ ICT NY	35-B6120-5R0
FDD 3.5" 1.44MB 12.7MM,360RPM	85-10175-010
SCREW M2.0*4.0L K1 BZ ICT	35-B6120-4R0
FDD SHIELDING PLATE SUS 320	33-32011-000
FDD HOUSING	39-32022-001
SCREW M2.6*3.5L F NI ICT	35-21126-350
FPC CABLE FOR FDD V3.0	43-32002-003