

Addendum for LI-7000 System

SynthCore Lite Application for Windows NT 4.0

The CD contains a SynthCore Lite application program, that the Quick Settings Guide does not describe. It can be installed by running win-wave.exe in the D:\drive-all\sigmatel\win-wave directory. (Were D is your CD-ROM drive letter).

Note that the NT4 installation requires a manual step at the end of the installation. This step applies to NT4 only. (NT4 Service Pack 4 has to be installed, Service Pack 4 includes DirectSound 3)

- 1) After you run the normal installer, DO NOT reboot your system yet.
- 2) Go to Start > Settings > Control Panel > Multi Media
- 3) Select the "Devices" tab
- 4) Select the "Add" Button
- 5) Select "Unlisted or Undated Driver"
- 6) Browse to c:\Program Files\Staccato\SynthCore Lite\oemsetup.inf and select this file.
- 7) Now look under the MIDI Devices tab, you should see the Staccato MIDI driver.
- 8) Reboot your machine.

This finishes the installation process.

Following is a list of known issues for the LI-7000 System

1. Other than the Quick Settings Guide and Manual state, there is no AC97 Sigmatel Codec driver for Win95. The Windows 98 and NT Drivers are available on the CD.
 - *The Win 95 driver will be released as soon as Sigmatel Inc. makes it available.*

<http://www.soyo.com.tw> periodically. Please go to Soyo web site to check for new driver and BIOS releases regularly.