KB-6130 (25-10894-30/Jan. 1999)

The mainboard had been improved to support more CPU frequency selections since this manual was printed. The new table below is used to replace the table on Page 19.

Bus Frequency = 100MHz	Bus Frequency = 66MHz	Switches Settings
350MHz	233MHz	
400MHz	266MHz	
450MHz	300MHz	
500MHz	333MHz	6 5 4 3 2 1 ON
550MHz	366MHz	
600MHz	400MHz	6 5 4 3 2 1 0 0 0 0 0