


# Mainboard Layout



➔ **NOTE :** When plugging your processor into the CPU (ZIF) socket, make sure that pin 1 matches that of the CPU socket.