

## Table of Contents

### Chapter 1 Overview

Package Checklist .....	1-2
P4-865PE MAX	
P4-865PE Ultra	
P4-865P Ultra .....	1-3
Main Features .....	1-4
FIC Unique Innovation for Users (NOVUS) - Enhanced Mainboard Features and System Support .....	1-6

### Chapter 2 Installation Procedures

1). Set System Jumpers .....	2-2
Clear CMOS .....	2-2
2). Install Memory Modules .....	2-3
3). Install the CPU .....	2-4
Connect ATX Power .....	2-5
4). Install Expansion Cards .....	2-6
5). Connect Devices .....	2-8
Floppy Diskette Drive Connector .....	2-8
IDE Device Connectors .....	2-8
Fan Connectors .....	2-9
Power Connectors .....	2-9
Front Panel Block, Power LED, IR, and Speaker Connector	2-10
Serial ATA Connectors .....	2-11
CD Audio-In Connector .....	2-12
1394 Connectors (optional) .....	2-12
PS/2 Keyboard and Mouse Connector .....	2-13
RJ45 LAN Connector .....	2-13
Serial Port Connectors .....	2-14
Printer Connector .....	2-14
Audio I/O Jacks .....	2-15
Front Audio Connector .....	2-15
5.1 Audio Channel Feature .....	2-16
Universal Serial Bus Connectors .....	2-17

**Chapter 3 BIOS Setup**

CMOS Setup Utility .....	3-1
Standard CMOS Setup .....	3-2
Advanced BIOS Features .....	3-4
Advanced Chipset Features .....	3-8
Integrated Peripherals .....	3-10
Power Management Setup .....	3-13
PnP/PCI Configurations .....	3-17
PC Health Status .....	3-18
Frequency/Voltage Control .....	3-19
Load Fail-Safe Defaults .....	3-20
Load Optimized Defaults .....	3-20
Supervisor/User Password .....	3-20
Save and Exit Setup .....	3-22
Exit without Saving .....	3-22