

5I-TX1 JUMPER SETTINGS

INTEL® PENTIUM® CPU	CLOCK SPEED	RATIO	JP1	JP2	JP3	JP6	JP7	JP8	JP10
P54C 75 3.3V	50MHZ	1.5	1-2	1-2	1-2	ON	OFF	OFF	1-2,5-6,7-8
P54C 90 3.3V	60MHZ	1.5	1-2	1-2	2-3	ON	OFF	OFF	1-2,5-6,7-8
P54C 100 3.3V	66MHZ	1.5	1-2	2-3	1-2	ON	OFF	OFF	1-2,5-6,7-8
P54C 120 3.3V	60MHZ	2	1-2	1-2	2-3	ON	1-2	OFF	1-2,5-6,7-8
P54C 133 3.3V	66MHZ	2	1-2	2-3	1-2	ON	1-2	OFF	1-2,5-6,7-8
P54C 150 3.3V	60MHZ	2.5	1-2	1-2	2-3	ON	1-2, 3-4	OFF	1-2,5-6,7-8
P54C 166 3.3V	66MHZ	2.5	1-2	2-3	1-2	ON	1-2, 3-4	OFF	1-2,5-6,7-8
P55C 166 2.8/3.3V	66MHZ	2.5	1-2	2-3	1-2	OFF	1-2, 3-4	1-2,3-4	7-8
P54C 180 3.3V	60MHZ	3	1-2	1-2	2-3	ON	3-4	OFF	1-2,5-6,7-8
P54C 200 3.3V	66MHZ	3	1-2	2-3	1-2	ON	3-4	OFF	1-2,5-6,7-8
P55C 200 2.8/3.3V	66MHZ	3	1-2	2-3	1-2	OFF	3-4	1-2,3-4	7-8
P55C 233 2.8/3.3V	66MHZ	3.5	1-2	2-3	1-2	OFF	OFF	1-2,3-4	7-8

AMD® CPU	CLOCK SPEED	RATIO	JP1	JP2	JP3	JP6	JP7	JP8	JP10
PR75 3.52V	50MHZ	1.5	1-2	1-2	1-2	ON	OFF	OFF	1-2,3-4,5-6,7-8
PR90/PR120 3.52V	60MHZ	1.5	1-2	1-2	2-3	ON	OFF	OFF	1-2,3-4,5-6,7-8
PR100/PR133 3.52V	66MHZ	1.5	1-2	2-3	1-2	ON	OFF	OFF	1-2,3-4,5-6,7-8
PR150 3.52V	60MHZ	2.5	1-2	1-2	2-3	ON	1-2, 3-4	OFF	1-2,3-4,5-6,7-8
PR166 3.52V	66MHZ	2.5	1-2	2-3	1-2	ON	1-2, 3-4	OFF	1-2,3-4,5-6,7-8
K6 PR166 2.9/3.3V	66MHZ	2.5	1-2	2-3	1-2	OFF	1-2, 3-4	1-2,3-4	1-2, 7-8
K6 PR200 2.9/3.3V	66MHZ	3	1-2	2-3	1-2	OFF	3-4	1-2,3-4	1-2, 7-8
K6 PR233 3.2/3.3V	66MHZ	3.5	1-2	2-3	1-2	OFF	OFF	1-2,3-4	5-6, 7-8
K6 PR266 2.2/3.3V	66MHZ	4	1-2	2-3	1-2	OFF	1-2, 5-6	1-2,3-4	3-4
K6 PR300 2.2/3.45V	66MHZ	4.5	1-2	2-3	1-2	OFF	1-2, 3-4, 5-6	1-2,3-4	3-4

CYRIX® CPU	CLOCK SPEED	RATIO	JP1	JP2	JP3	JP6	JP7	JP8	JP10
P120+ 3.52V	50MHZ	2	1-2	1-2	1-2	ON	1-2	OFF	1-2,3-4,5-6,7-8
P133+ 3.52V	55MHZ	2	2-3	1-2	1-2	ON	1-2	OFF	1-2,3-4,5-6,7-8
P150+ 3.52V	60MHZ	2	1-2	1-2	2-3	ON	1-2	OFF	1-2,3-4,5-6,7-8
P166+ 3.52V	66MHZ	2	1-2	2-3	1-2	ON	1-2	OFF	1-2,3-4,5-6,7-8
P200 + 3.52V	75MHZ	2	2-3	1-2	2-3	ON	1-2	OFF	1-2,3-4,5-6,7-8
P133+ 2.8/3.3V 6X86L	55MHZ	2	2-3	1-2	1-2	OFF	1-2	1-2, 3-4	7-8
P150+ 2.8/3.3V 6X86L	60MHZ	2	1-2	1-2	2-3	OFF	1-2	1-2, 3-4	7-8
P166+ 2.8/3.3V 6X86L	66MHZ	2	1-2	2-3	1-2	OFF	1-2	1-2, 3-4	7-8
P200 + 2.8/3.3V 6X86L	75MHZ	2	2-3	1-2	2-3	OFF	1-2	1-2, 3-4	7-8
MX PR166 2.9/3.3V	60MHZ	2.5	1-2	1-2	2-3	OFF	1-2, 3-4	1-2, 3-4	1-2,7-8
MX PP166 2.9/3.3V	66MHZ	2	1-2	2-3	1-2	OFF	1-2	1-2, 3-4	1-2,7-8
MX PR200 2.9/3.3V	75MHZ	2	2-3	1-2	2-3	OFF	1-2	1-2, 3-4	1-2,7-8
MX PR233 2.9/3.3V	75MHZ	2.5	2-3	1-2	2-3	OFF	1-2,3-4	1-2,3-4	1-2,7-8
MII PR300 2.9/3.3V	66 MHZ	3.5	1-2	2-3	1-2	OFF	OFF	1-2, 3-4	1-2, 7-8