

# Contents

<b>Chapter 1 Specification .....</b>	<b>8</b>
<b>1-1 KT400-C Mainboard Layout** .....</b>	<b>9</b>
<b>1-2 Mainboard Specifications .....</b>	<b>10</b>
1-2.1 CPU Socket .....	10
1-2.2 System Chipsets .....	10
1-2.3 Memory .....	10
1-2.4 BIOS .....	10
1-2.5 Accelerated Graphics Port (AGP) Interface .....	10
1-2.6 Advanced System Power Management .....	11
1-2.7 Multi-I/O Functions .....	11
1-2.8 Expansion Slots .....	11
1-2.9 AC'97 Audio Codec on board .....	12
1-2.10 Hardware Monitor on board .....	12
1-2.11 Form Factor .....	12
<b>1-3 Mainboard Specification Table .....</b>	<b>13</b>
<b>1-4 Chipset System Block Diagram .....</b>	<b>14</b>
<b>Chapter 2 Hardware Setup .....</b>	<b>16</b>
<b>2-1 CPU Identification and Installation .....</b>	<b>17</b>
2-1.1 CPU Identification Legends .....	17
2-1.2 CPU Installation with Socket 462 .....	18
<b>2-2 Memory Installation .....</b>	<b>19</b>
2-2.1 To Install DDR SDRAM Module .....	19
2-2.2 To Remove a DIMM .....	20
<b>2-3 AGP Slot Installation .....</b>	<b>21</b>
<b>2-4 IDE Connector Installation .....</b>	<b>22</b>
<b>2-5 Floppy Drive Connector ( FDC ) Installation .....</b>	<b>23</b>
<b>2-6 ATX Power Supply Installation .....</b>	<b>24</b>

<b>2-7 Jumper / Switch Settings .....</b>	<b>25</b>
2-7.1 How to tackle the Jumpers: .....	26
2-7.2 SW1: CPU Clock/Overclock Select .....	26
2-7.3 JBAT1: Clear CMOS .....	27
2-7.4 Jp1: Anti-burn Shield (ABSII) .....	28
2-7.5 JP2: KB/Mouse Power On / Wake Up .....	29
<b>2-8 Other Connectors Configuration .....</b>	<b>30</b>
2-8.1 On-board FAN Connectors .....	30
2-8.2 USB Ports and USB Pin-headers .....	31
2-8.3 Chassis Panel Connectors .....	32
2-8.4 PS/2 Mouse and PS/2 Keyboard .....	32
2-8.5 CD-ROM Audio Connectors (CD-In1) .....	33
2-8.6 Thermal Connectors.....	34
2-8.7 Complex Pin-header (Front Panel Connectors) .....	35
2-8.8 JAUD1: Front Panel Audio Connector (optional) .....	37
<b>Chapter 3 Software Setup .....</b>	<b>38</b>
3-1 Open Up Support CD: .....	39
3-2 Proceed to VIA 4-IN-1 Drivers Installation .....	40
3-3 Proceed to AC'97 Audio Driver Installation .....	42
3-4 Install USB 2.0 Driver for Win98 / Me / 2000 / XP .....	43
3-5 To Install Hardware Monitor Utility .....	45
3-5.1 Installation .....	45
3-5.2 Verification .....	46
<b>Chapter 4 AMI BIOS Setup .....</b>	<b>48</b>
4-1 About BIOS Setup .....	49
4-2 To Run BIOS Setup .....	49
4-3 About CMOS .....	49
4-4 The POST ( Power On Self Test ) .....	49

<b>4-5 To Update BIOS .....</b>	<b>50</b>
<b>4-6 BIOS SETUP --- CMOS Setup Utility .....</b>	<b>52</b>
4-6.1 CMOS Setup Utility .....	52
4-6.2 Standard CMOS Setup .....	53
4-6.3 Advanced BIOS Features .....	56
4-6.4 Advanced Chipset Features .....	59
4-6.5 Power Management Features .....	62
4-6.6 PNP / PCI Configurations .....	65
4-6.7 Integrated Peripherals .....	67
4-6.8 SmartDoc Anti-Burn Shield .....	70
4-6.9 Frequency/Voltage Control .....	72
4-6.10 System Information .....	74
4-6.11 Set Supervisor Password .....	75
4-6.12 Load Optimized Defaults .....	77
4-6.13 Save & Exit Setup .....	77
4-6.14 Exit Without Saving .....	77
<b>APPENDICES .....</b>	<b>78</b>
Appendix-1 Identify Mainboard Model Number .....	79
Appendix-2 Technical Terms .....	80

## **ITEM CHECKUP**

---

- Mainboard
- Mainboard User Manual
- Multi-lingual Quick Installation Guide
- Support CD
- Bundled Bonus Pack CD
- Bundled Bonus Pack Manual
- Cables :
  - ATA66/100/133 IDE Cable
  - FDD Cable
  - USB Cable (Optional)