









The 5VIA73 Mainboard layout



JP2	1-2	3-4	5-6	7-8	CPU FSB	PCI FSB
	OFF	OFF	OFF	OFF	60	30
	ON	OFF	OFF	OFF	66.8	33.4
	OFF	ON	OFF	OFF	70	35
	ON	ON	OFF	OFF	75	25
	ON	OFF	ON	OFF	83.3	27.76
	OFF	ON	ON	OFF	95.25	31.75
	ON	ON	ON	OFF	100	33.33
	OFF	OFF	OFF	ON	75	37.5
	ON	OFF	OFF	ON	80	40
	OFF	ON	OFF	ON	83.3	41.65
	ON	ON	OFF	ON	105(103)	35
	OFF	OFF	ON	ON	110(107)	36.67
	ON	OFF	ON	ON	115(112)	38.33
	OFF	ON	ON	ON	120(117)	40
	ON	ON	ON	ON	124(122)	41.33



J5	J6	J7	Description
CLOSE	CLOSE	1-2	AC'97 Function
CLOSE	OPEN	3-4	MC'97 Function
CLOSE	CLOSE	1-2,3-4	AC'97+MC'97 Function
CLOSE	OPEN	3-4	AMR Function

JP1 CPU Core Voltage Selection (1-5)

CPU Voltage	9-10	7-8	5-6	3-4	1-2	Vcore
	OFF	OFF	OFF	OFF	OFF	0
	OFF	OFF	OFF	OFF	ON	2.1
	OFF	OFF	OFF	ON	OFF	2.2
	OFF	OFF	OFF	ON	ON	2.3
	OFF	OFF	ON	OFF	OFF	2.4
	OFF	OFF	ON	OFF	ON	2.5
	OFF	OFF	ON	ON	OFF	2.6
	OFF	OFF	ON	ON	ON	2.7
	OFF	ON	OFF	OFF	OFF	2.8
	OFF	ON	OFF	OFF	ON	2.9
	OFF	ON	OFF	ON	OFF	3.0
	OFF	ON	OFF	ON	ON	3.1
	OFF	ON	ON	OFF	OFF	3.2
	OFF	ON	ON	OFF	ON	3.3
	OFF	ON	ON	ON	OFF	3.4
	OFF	ON	ON	ON	ON	3.5

JP1 CPU Core Voltage Selection (1-5)

CPU Voltage	9-10	7-8	5-6	3-4	1-2	Vcore
	ON	ON	ON	ON	ON	2.05
	ON	ON	ON	ON	OFF	2.00
	ON	ON	ON	OFF	ON	1.95
	ON	ON	ON	OFF	OFF	1.90
	ON	ON	OFF	ON	ON	1.85
	ON	ON	OFF	ON	OFF	1.8
	ON	ON	OFF	OFF	ON	1.75
	ON	ON	OFF	OFF	OFF	1.7
	ON	OFF	ON	ON	ON	1.65
	ON	OFF	ON	ON	OFF	1.6
	ON	OFF	ON	OFF	ON	1.55
	ON	OFF	ON	OFF	OFF	1.50
	ON	OFF	OFF	ON	ON	1.45
	ON	OFF	OFF	ON	OFF	1.40
	ON	OFF	OFF	OFF	ON	1.35
	ON	OFF	OFF	OFF	OFF	1.30

JP1 CPU Ratio Selection (6-8)

CPU Ratio	15-16	13-14	11-12	Ratio
	OFF	ON	ON	2.5
	OFF	ON	OFF	3.0
	OFF	OFF	ON	2.0
	OFF	OFF	OFF	1.5/3.5
	ON	ON	ON	4.5
	ON	ON	OFF	5.0
	ON	OFF	ON	4.0
	ON	OFF	OFF	5.5